




SERVICE MANUAL

DIGITAL VIDEO CAMERA

GR-D370UC, GR-D370US, GR-D371US, GR-D372US, GR-D375UC, GR-D375US, GR-D390UC, GR-D390US, GR-D395US, GR-D396US



Mini DV NTSC



MultiMediaCard

GR-D370UC3M, GR-D370US3M, GR-D371US3M,
GR-D372US3M, GR-D375UC3M, GR-D375US3M,
GR-D390UC3M, GR-D390US3M, GR-D395US3M,
GR-D396US3M [M6D1S5]

There are two types in this model.

Although these two types are not different in appearance, they have different signal processing electrical circuits on the MAIN PWB.

This model type is identified from the previous model type by the indication of the rating label on the cabinet.

Please refer to below <How to identify the model>.

This service manual <YF124B> describes only the items which differ from those of already issued service manual <YF124>.

For details other than those described in this manual, please refer to the service manuals which were already issued.

<How to identify the model>

1. By rating label

[3] is marked under the name of this model type.

(Refer to Fig.1)

2. By MAIN PWB number

Service manual <YF124>:LYB10065 series

Service manual <YF124B>:LYB10075 series

<Example>




Fig.1

SPECIFICATION

■Camcorder

For General	Power supply		DC 11 V (Using AC Adapter) DC 7.2 V (Using battery pack)
	Power consumption		Approx. 2.8 W (3.0 W*) (LCD monitor off, viewfinder on) Approx. 3.2 W (3.4 W*) (LCD monitor on, viewfinder off) Approx. 6.5 W (Maximum; when charging the battery pack) * Using LED Light
	Dimensions (W × H × D)		59 mm × 94 mm × 114 mm (2-5/16" × 3-11/16" × 4-1/2") (with the LCD monitor closed and the viewfinder pushed back in)
	Weight		Approx. 400g (0.88 lbs) (without battery, cassette and lens cap) Approx. 480 g (1.1 lbs) / Approx. 525 g (1.16 lbs)(GR-D395 only) (incl. battery, cassette and lens cap)
	Operating temperature		0°C to 40°C (32°F to 104°F)
	Operating humidity		35% to 80%
	Storage temperature		-20°C to 50°C (-4°F to 122°F)
	Pickup		1/6" CCD
	Lens		F 2.0, f = 2.3 mm to 73.6 mm, 32:1 power zoom lens
	Filter diameter		Ø27 mm
	LCD monitor		2.5" diagonally measured, LCD panel/TFT active matrix system
	Viewfinder		Electronic viewfinder with 0.33" color LCD
	Speaker		Monaural
	LED Light		Effective distance: 1.5 m (5 ft)
For Digital Video Camera	Format		DV format (SD mode)
	Signal format		NTSC standard
	Recording/Playback format	Video	Digital component recording
		Audio	PCM digital recording, 32 kHz 4-channel (12-BIT), 48 kHz 2-channel (16-BIT)
	Cassette		Mini DV cassette
	Tape speed		SP: 18.8 mm/s, LP: 12.5 mm/s
For Digital Still Camera	Maximum recording time (using 80 min. cassette)		SP: 80 min., LP: 120 min.
	Storage media		SD Memory Card/MultiMediaCard
	Compression system		JPEG (compatible)
	File size		Still image : 1 mode (640 × 480 pixels)
For Connectors	Picture quality		2 modes (FINE/STANDARD)
	AV	Video output	1.0 V (p-p), 75Ω, analog
		Audio output	300 mV (rms), 1 kΩ, analog, stereo
	DV	Input/output	4-pin, IEEE 1394 compliant
	USB		Mini USB-B type, USB 1.1 compliant

■AC Adapter

Power requirement	AC 110 V to 240 V, 50 Hz/60 Hz
Output	DC 11 V, 1 A

Specifications shown are for SP mode unless otherwise indicated. E & O.E. Design and specifications subject to change without notice.

SECTION 1 PRECAUTION

Please refer to "GR-D370US No.YF124" about this section.

SECTION 2 SPECIFIC SERVICE INSTRUCTIONS

2.1 DIFFERENCE LIST

The following table indicate main different points between models GR-D370UC, GR-D370US, GR-D371US, GR-D372US, GR-D375UC, GR-D375US, GR-D390US, GR-D390US, GR-D395US, GR-D396US.

MODEL NAME	GR-D370UC	GR-D370US	GR-D371US
MEMORY CARD	NO(OPTIONAL)	NO(OPTIONAL)	NO(OPTIONAL)
REMOTE CONTROL	NO	NO	RM-V720U
BATTERY PACK	BN-VF707US	BN-VF707US	BN-VF707US

MODEL NAME	GR-D372US	GR-D375UC	GR-D375US
MEMORY CARD	NO(OPTIONAL)	NO(OPTIONAL)	NO(OPTIONAL)
REMOTE CONTROL	NO	RM-V720U	RM-V720U
BATTERY	BN-VF707US	BN-VF707US	BN-VF707US

MODEL NAME	GR-D390UC	GR-D390US	GR-D395US
MEMORY CARD	YES(PROVIDED)	YES(PROVIDED)	NO(OPTIONAL)
REMOTE CONTROL	RM-V720U	RM-V720U	RM-V720U
BATTERY	BN-VF707US	N-VF707US	BN-VF714US

MODEL NAME	GR-D396US
MEMORY CARD	NO(OPTIONAL)
REMOTE CONTROL	RM-V720U
BATTERY	BN-VF707US × 2

SECTION 3 DISASSEMBLY

Please refer to "GR-D370US No.YF124" about this section.

SECTION 4 ADJUSTMENT

Please refer to "GR-D370US No.YF124" about this section.

SECTION 5 TROUBLESHOOTING

Please refer to "GR-D370US No.YF124" about this section.



Victor Company of Japan, Limited
Camcorder Category 12, 3-chome, Moriya-cho, kanagawa-ku, Yokohama, kanagawa-prefecture, 221-8528, Japan

(No.YF124B)




Printed in Japan
VPT

JVC

SERVICE MANUAL

DIGITAL VIDEO CAMERA

GR-D370UC, GR-D370US, GR-D371US, GR-D375UC, GR-D375US, GR-D390UC, GR-D390US, GR-D395US, GR-D396US



Mini **DV** NTSC



MultiMediaCard

GR-D370UCM, GR-D370USM, GR-D371USM,
GR-D375UCM, GR-D375USM, GR-D390UCM,
GR-D390USM, GR-D395USM, GR-D396USM [M6D1S5]

For disassembling and assembling of MECHANISM ASSEMBLY, refer to the SERVICE MANUAL No.YF081(MECHANISM ASSEMBLY).
Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)

TABLE OF CONTENTS

1	PRECAUTIONS	1-3
2	SPECIFIC SERVICE INSTRUCTIONS	1-5
3	DISASSEMBLY	1-6
4	ADJUSTMENT	1-16
5	TROUBLE SHOOTING	1-20

SPECIFICATION

■Camcorder

For General	Power supply		DC 11 V (Using AC Adapter) DC 7.2 V (Using battery pack)
	Power consumption		Approx. 2.8 W (3.0 W*) (LCD monitor off, viewfinder on) Approx. 3.2 W (3.4 W*) (LCD monitor on, viewfinder off) Approx. 6.5 W (Maximum; when charging the battery pack) * Using LED Light
	Dimensions (W × H × D)		59 mm × 94 mm × 114 mm (2-5/16" × 3-11/16" × 4-1/2") (with the LCD monitor closed and the viewfinder pushed back in)
	Weight		Approx. 400g (0.88 lbs) (without battery, cassette and lens cap) Approx. 480 g (1.1 lbs) / Approx. 525 g (1.16 lbs)(GR-D395 only) (incl. battery, cassette and lens cap)
	Operating temperature		0°C to 40°C (32°F to 104°F)
	Operating humidity		35% to 80%
	Storage temperature		-20°C to 50°C (-4°F to 122°F)
	Pickup		1/6" CCD
	Lens		F 2.0, f = 2.3 mm to 73.6 mm, 32:1 power zoom lens
	Filter diameter		Ø27 mm
	LCD monitor		2.5" diagonally measured, LCD panel/TFT active matrix system
	Viewfinder		Electronic viewfinder with 0.33" color LCD
	Speaker		Monaural
	LED Light		Effective distance: 1.5 m (5 ft)
For Digital Video Camera	Format		DV format (SD mode)
	Signal format		NTSC standard
	Recording/Playback format	Video	Digital component recording
		Audio	PCM digital recording, 32 kHz 4-channel (12-BIT), 48 kHz 2-channel (16-BIT)
	Cassette		Mini DV cassette
	Tape speed		SP: 18.8 mm/s, LP: 12.5 mm/s
For Digital Still Camera	Maximum recording time (using 80 min. cassette)		SP: 80 min., LP: 120 min.
	Storage media		SD Memory Card/MultiMediaCard
	Compression system		JPEG (compatible)
	File size		Still image : 1 mode (640 × 480 pixels)
For Connectors	Picture quality		2 modes (FINE/STANDARD)
	AV	Video output	1.0 V (p-p), 75Ω, analog
		Audio output	300 mV (rms), 1 kΩ, analog, stereo
	DV	Input/output	4-pin, IEEE 1394 compliant
	USB		Mini USB-B type, USB 1.1 compliant

■AC Adapter

Power requirement	AC 110 V to 240 V, 50 Hz/60 Hz
Output	DC 11 V, 1 A

Specifications shown are for SP mode unless otherwise indicated. E & O.E. Design and specifications subject to change without notice.

SECTION 1 PRECAUTIONS

1.1 SAFTY PRECAUTIONS

Prior to shipment from the factory, JVC products are strictly inspected to conform with the recognized product safety and electrical codes of the countries in which they are to be sold. However, in order to maintain such compliance, it is equally important to implement the following precautions when a set is being serviced.

1.1.1 Precautions during Servicing

- (1) Locations requiring special caution are denoted by labels and inscriptions on the cabinet, chassis and certain parts of the product. When performing service, be sure to read and comply with these and other cautionary notices appearing in the operation and service manuals.
- (2) Parts identified by the  symbol and shaded () parts are critical for safety. Replace only with specified part numbers.

NOTE :

Parts in this category also include those specified to comply with X-ray emission standards for products using cathode ray tubes and those specified for compliance with various regulations regarding spurious radiation emission.

- (3) Fuse replacement caution notice.
Caution for continued protection against fire hazard.
Replace only with same type and rated fuse(s) as specified.
- (4) Use specified internal wiring. Note especially:
 - Wires covered with PVC tubing
 - Double insulated wires
 - High voltage leads
- (5) Use specified insulating materials for hazardous live parts.
Note especially:
 - Insulation Tape
 - PVC tubing
 - Spacers
 - Insulation sheets for transistors
 - Barrier
- (6) When replacing AC primary side components (transformers, power cords, noise blocking capacitors, etc.) wrap ends of wires securely about the terminals before soldering.




Fig.1-1-1

- (7) Observe that wires do not contact heat producing parts (heatsinks, oxide metal film resistors, fusible resistors, etc.)
- (8) Check that replaced wires do not contact sharp edged or pointed parts.
- (9) When a power cord has been replaced, check that 10-15 kg of force in any direction will not loosen it.




Fig.1-1-2

- (10) Also check areas surrounding repaired locations.
- (11) Products using cathode ray tubes (CRTs) In regard to such products, the cathode ray tubes themselves, the high voltage circuits, and related circuits are specified for compliance with recognized codes pertaining to X-ray

emission. Consequently, when servicing these products, replace the cathode ray tubes and other parts with only the specified parts. Under no circumstances attempt to modify these circuits. Unauthorized modification can increase the high voltage value and cause X-ray emission from the cathode ray tube.


- (12) Crimp type wire connector In such cases as when replacing the power transformer in sets where the connections between the power cord and power transformer primary lead wires are performed using crimp type connectors, if replacing the connectors is unavoidable, in order to prevent safety hazards, perform carefully and precisely according to the following steps.

• **Connector part number** :E03830-001

• **Required tool** : Connector crimping tool of the proper type which will not damage insulated parts.

• **Replacement procedure**

- a) Remove the old connector by cutting the wires at a point close to the connector. Important : Do not reuse a connector (discard it).



cut close to connector

Fig.1-1-3

- b) Strip about 15 mm of the insulation from the ends of the wires. If the wires are stranded, twist the strands to avoid frayed conductors.




Fig.1-1-4

- c) Align the lengths of the wires to be connected. Insert the wires fully into the connector.




Fig.1-1-5

- d) As shown in Fig.1-1-6, use the crimping tool to crimp the metal sleeve at the center position. Be sure to crimp fully to the complete closure of the tool.




Fig.1-1-6

- e) Check the four points noted in Fig.1-1-7.





Fig.1-1-7

1.1.2 Safety Check after Servicing

Examine the area surrounding the repaired location for damage or deterioration. Observe that screws, parts and wires have been returned to original positions. Afterwards, perform the following tests and confirm the specified values in order to verify compliance with safety standards.

- (1) Insulation resistance test
- Confirm the specified insulation resistance or greater between power cord plug prongs and externally exposed parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.).See table 1 below.
- (2) Dielectric strength test
- Confirm specified dielectric strength or greater between power cord plug prongs and exposed accessible parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.). See Fig.1-1-11 below.
- (3) Clearance distance
- When replacing primary circuit components, confirm specified clearance distance (d), (d') between soldered terminals, and between terminals and surrounding metallic parts. See Fig.1-1-11 below.



- (4) Leakage current test
- Confirm specified or lower leakage current between earth ground/power cord plug prongs and externally exposed accessible parts (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.).
- Measuring Method : (Power ON)Insert load Z between earth ground/power cord plug prongs and externally exposed accessible parts. Use an AC voltmeter to measure across both terminals of load Z. See Fig.1-1-9 and following Fig.1-1-12.





Fig.1-1-9

- (5) Grounding (Class 1 model only)
- Confirm specified or lower grounding impedance between earth pin in AC inlet and externally exposed accessible parts (Video in, Video out, Audio in, Audio out or Fixing screw etc.).Measuring Method:
- Connect milli ohm meter between earth pin in AC inlet and exposed accessible parts. See Fig.1-1-10 and grounding specifications.



Grounding Specifications

Region	Grounding Impedance (Z)
USA & Canada	$Z \leq 0.1 \text{ ohm}$
Europe & Australia	$Z \leq 0.5 \text{ ohm}$

Fig.1-1-10

AC Line Voltage	Region	Insulation Resistance (R)	Dielectric Strength	Clearance Distance (d), (d')
100 V	Japan	$R \geq 1 \text{ M}\Omega/500 \text{ V DC}$	AC 1 kV 1 minute	$d, d' \geq 3 \text{ mm}$
100 to 240 V			AC 1.5 kV 1 minute	$d, d' \geq 4 \text{ mm}$
110 to 130 V	USA & Canada	$1 \text{ M}\Omega \leq R \leq 12 \text{ M}\Omega/500 \text{ V DC}$	AC 1 kV 1 minute	$d, d' \geq 3.2 \text{ mm}$
110 to 130 V	Europe & Australia	$R \geq 10 \text{ M}\Omega/500 \text{ V DC}$	AC 3 kV 1 minute (Class II)	$d \geq 4 \text{ mm}$
200 to 240 V			AC 1.5 kV 1 minute (Class I)	$d' \geq 8 \text{ mm (Power cord)}$ $d' \geq 6 \text{ mm (Primary wire)}$

Fig.1-1-11

AC Line Voltage	Region	Load Z	Leakage Current (i)	a, b, c
100 V	Japan		$i \leq 1 \text{ mA rms}$	Exposed accessible parts
110 to 130 V	USA & Canada		$i \leq 0.5 \text{ mA rms}$	Exposed accessible parts
110 to 130 V 220 to 240 V	Europe & Australia		$i \leq 0.7 \text{ mA peak}$ $i \leq 2 \text{ mA dc}$	Antenna earth terminals
			$i \leq 0.7 \text{ mA peak}$ $i \leq 2 \text{ mA dc}$	Other terminals

Fig.1-1-12

NOTE :

These tables are unofficial and for reference only. Be sure to confirm the precise values for your particular country and locality.

SECTION 2

SPECIFIC SERVICE INSTRUCTIONS

2.1 DIFFERENCE LIST

The following table indicate main different points between models GR-D370UC, GR-D370US, GR-D371US, GR-D375UC, GR-D375US, GR-D390UC, GR-D390US, GR-D395US and GR-D396US.

MODEL NAME	GR-D370UC	GR-D370US	GR-D371US
MEMORY CARD	NO(OPTIONAL)	NO(OPTIONAL)	NO(OPTIONAL)
REMOTE CONTROL	NO	NO	RM-V720U
BATTERY PACK	BN-VF707US	BN-VF707US	BN-VF707US

MODEL NAME	GR-D375UC	GR-D375US	GR-D390UC
MEMORY CARD	NO(OPTIONAL)	NO(OPTIONAL)	YES(PROVIDED)
REMOTE CONTROL	RM-V720U	RM-V720U	RM-V720U
BATTERY	BN-VF707US	BN-VF707US	BN-VF707US

MODEL NAME	GR-D390US	GR-D395US	GR-D396US
MEMORY CARD	YES(PROVIDED)	NO(OPTIONAL)	NO(OPTIONAL)
REMOTE CONTROL	RM-V720U	RM-V720U	RM-V720U
BATTERY	BN-VF707US	BN-VF714US	BN-VF707US × 2

SECTION 3 DISASSEMBLY

3.1 BEFORE ASSEMBLY AND DISASSEMBLY

3.1.1 Precautions

- Be sure to disconnect the power supply unit prior to mounting and soldering of parts.
- Prior to removing a component part that needs to disconnect its connector(s) and its screw(s), first disconnect the wire(s) from the connector(s), and then remove the screw(s).
- When connecting/disconnecting wires, pay enough attention not to damage the connectors.
- When inserting the flat wire to the connector, pay attention to the direction of the flat wire.
- Be careful in removing the parts to which some spacer or shield is attached for reinforcement or insulation.
- When replacing chip parts (especially IC parts), first remove the solder completely to prevent peeling of the pattern.
- Tighten screws properly during the procedures. Unless otherwise specified, tighten screws at a torque of 0.098N·m (1.0kgf·cm). However, as this is a required value at the time of production, use the value as a measuring stick when proceeding repair services. (See "SERVICE NOTE" as for tightening torque.)

3.1.2 Destination of connectors

Two kinds of double-arrows in connection tables respectively show kinds of connector/wires.

↔ : Flat wire ↔ : Wire ↔ : Board to board (B-B)
 □ : The connector of the side to remove

CONN. No.	CONNECTOR				PIN No.	
CN2a	MAIN	CN101	↔	MONI BW	CN761	40
CN2b	MAIN	CN103	↔	MINI BW	CN762	10

3.1.3 Disconnection of connectors (Wires)




Fig.3-1-1

3.1.4 Tools required for disassembly and assembly

Torque driver YTU94088	Bit YTU94088-003	Tweezers P-895
Chip IC replacement jig PTS40844-2	Cleaning cloth KSMM-01	

Fig.3-1-2

- **Torque driver**
Be sure to use to fastening the mechanism and exterior parts because those parts must strictly be controlled for tightening torque.
- **Bit**
This bit is slightly longer than those set in conventional torque drivers.
- **Tweezers**
To be used for removing and installing parts and wires.
- **Chip IC replacement jig**
To be used for replacement of IC.
- **Cleaning cloth**
Recommended cleaning cloth to wipe down the video heads, mechanism (tape transport system), optical lens surface.

3.2 ASSEMBLY AND DISASSEMBLY OF MAIN PARTS

3.2.1 Assembly and disassembly

When reassembling, perform the step(s) in reverse order.

STEP No.	PART	Fig. No.	POINT	NOTE
[1]	TOP COVER ASSY	C1	4(S1a), 3(L1a), CN1a	-
[2]	UPPER ASSY (Inc. VF ASSY, SPEAKER/MONITOR)	C2-1	(S2a), 2(S2b), 3(S2c) 2(SD1a), L2, CN2a, b	-
[8]	E.VF UNIT(B/W)	C2-2	2(S8), L8, CN8a	NOTE 8
(*1)	(*2)	(*3)	(*4)	(*5)

(*1) Order of steps in Procedure

When reassembling, perform the step(s) in the reverse order. These numbers are also used as the identification (location) No. of parts Figures.

(*2) Part to be removed or installed.

(*3) Fig. No. showing Procedure or Part Location.

(*4) Identification of part to be removed, unhooked, unlocked, released, unplugged, unclamped or unsoldered.

S = Screw L = Lock, Release, Hook
 SD = Solder CN = Connector

[Example]

- 4 (S1a) = Remove 4 S1a screws.
- 3 (L1a) = Disengage 3 L1a hooks.
- 2 (SD1a) = Unsolder 2 SD1a points.
- CN1a = Remove a CN1a connector.

(*5) Adjustment information for installation.

3.2.2 ASSEMBLY/DISASSEMBLY OF CABINET PARTS AND ELECTRICAL PARTS

●Disassembly procedure

STEP No.	PART NAME	Fig. No.	POINT	NOTE
[1]	UPPER ASSY	FA1-1	S1a,2(S1b),3(S1c),S1d	NOTE1a
		FA1-2	L1a,L1b,CN1	NOTE1b
[2]	OPE PWB ASSY	FA2-1	CN2a,b,c,S2a,4(S2b),KNOB(SLIDE)	NOTE2a,b,c
[3]	COVER (HINGE)	FA2-2	2(S3)	-
[4]	MONITOR ASSY	FA2-3	2(S4),2(L4)	-
[5]	SPEAKER	FA2-4	BKT.(HINGE),2(L5)	NOTE5
[6]	ZOOM UNIT		3(S6),L6	-
[7]	FRONT ASSY	FA3	S7a,2(S7b),2(L7a),2(L7b),CN7	NOTE7
[8]	CASS.COVER	FA4	GRIP BELT,4(S8),3(L8)	NOTE8
[9]	VF ASSY	FA5	CN9a,S9a,b,c,CN9b	NOTE9a,b
[10]	REAR COVER ASSY	FA6	S10a,b,c,L10a,b	NOTE10
[11]	LOWER CASE ASSY	FA7	2(S11),CN11	NOTE11
[12]	REAR PWB ASSY	FA8	S12,L12,CN12	NOTE12
[13]	OP BLOCK ASSY		CN13,2(L13)	NOTE13
[14]	MAIN BKT ASSY	FA9	3(S14),L14a,b	-
[15]	MAIN PWB ASSY	FA10	CN15a,b,c,d,e,S15,L15a,b	-
[16]	FRAME ASSY		4(S16)	-

NOTE1a:

Open the MONITOR ASSY, and then remove the screw (No.7) which is next to the DV terminal.

NOTE1b:

When removing the UPPER ASSY, be careful in handling the FPC.

Also, be careful in wiring the FPC when attaching the UPPER ASSY.

NOTE2a:

During the procedure, be careful in handling the SWITCH.
When attaching, leave the MONITOR ASSY open.

NOTE2b:

When attaching, be careful in wiring.

NOTE2c:

During the procedure, be careful not to lose KNOB(SLIDE).

NOTE5:

When attaching, be careful in wiring (SPEAKER).

NOTE7:

When attaching, be careful to avoid placing the WIRE (MIC) on the front side, and make sure to place the WIRE (MIC) on the connector.

NOTE8:

Pull out the GLIP BELT first.

NOTE9a:

When removing the VF ASSY, pull out the FPC on the CCD BOARD ASSY from the MAIN BOARD ASSY first.

NOTE9b:

When removing, pull out the FPC by lifting up the VF ASSEMBLY.

NOTE10:

During the procedure, release the LOWER CASE ASSY in the direction of an arrow.

NOTE11:

During the procedure, be careful in handling the FPC.

NOTE12:

During the procedure, be careful not to damage the SWITCH.

During the procedure, leave the CASS. COVER closed.

NOTE13:

When attaching, be careful to avoid any uplift or unevenness of the CUSHION (OP).

●Destination of connectors

CN. No.	CONNECTOR				PIN No.
CN1	MAIN	CN103	⇔	OPE	CN401 30
CN2a	OPE	CN403	⇔	ZOOM UNIT	- 8
CN2b	OPE	CN404	⇔	SPEAKER	- 2
CN2c	OPE	CN402	⇔	MONITOR	CN7601 18/21
CN7	MAIN	CN2601	⇔	MIC	- 4
CN9a	MAIN	CN4201	⇔	CCD	CN5001 20
CN9b	MAIN	CN7801	⇔	VF	CN7001 24/23
CN11	REAR	CN502	⇔	POWER UNIT	- 7
CN12	MAIN	CN101	⇔	REAR	CN504 32
CN13	MAIN	CN4901	⇔	OP BLOCK	- 26
CN15a	MAIN	CN1604	⇔	SENSOR	- 16
CN15b	MAIN	CN1603	⇔	CAPSTAN MOTOR	- 18
CN15c	MAIN	CN1602	⇔	DRUM MOTOR	- 11
CN15d	MAIN	CN3501	⇔	HEAD	- 8
CN15e	MAIN	CN1601	⇔	LOADING MOTOR ROTARY ENCODER SW	- 8




Fig.FA1-1




Fig.FA2-1




Fig.FA1-2




Fig.FA2-2




Fig.FA2-3




Fig.FA3




Fig.FA2-4




Fig.FA4




Fig.FA5




Fig.FA7




Fig.FA6




Fig.FA8




Fig.FA9




Fig.FA10

3.2.3 ASSEMBLY/DISASSEMBLY OF [4] MONITOR ASSEMBLY

●CAUTIONS

- (1) During the procedure, be careful in handling the LCD MODULE and other parts. Pay special attention not to damage or soil the monitor screen.
If fingerprints are left on the screen, wipe them with clean chamois leather or a cleaning cloth.

●Removing MONITOR ASSEMBLY

- (1) Turn the HINGE UNIT ASSEMBLY 90°, and remove the two screws (1 and 2). Remove the M.COVER ASSY by removing the six hooks (L4a-f).
- (2) Pull out the U/D SWITCH BOARD from the MONITOR CASE ASSEMBLY.

NOTE4a:

During the procedure, be careful in handling the FPC.

- (3) Release the lock of the connector (CN4a), and remove the HINGE UNIT by lifting it up.
- (4) Release the lock of the connector (CN4b), and pull out the FPC.
- (5) Remove the screw (3), and Remove the MONI PWB ASSY by removing the hook (L4g).

NOTE4b:

When attaching the MONITOR BOARD ASSEMBLY, be careful to avoid any misalignment or unevenness of the parts underneath.

- (6) Remove the SHEET (M.REF), LIGHT GUIDE, SHEET (M.DIFF) and the SHEET(BEF).
- (7) Remove the S.CASE(MONI), LCD MODULE and the LCD CASE.

NOTE4c:

During the procedure, handle the three parts (LCD CASE, LCD MODULE, and S.CASE(MONI)) together.

●Removing HINGE UNIT ASSEMBLY

- (1) Remove the screw (4), and Remove the H.COVER(U,L).

NOTE4d:

During the procedure, be careful in handling the magnet.

When attaching, set the negative pole outside as shown in the figure. Be careful when removing as there is no marking.

NOTE4e:

During the procedure, be careful in handling the FPC.

NOTE4f:

The FPC is rolled around the axis of rotation of the HINGE ASSEMBLY 2.5 rounds (2.5times).

The connecting side to the MONITOR BOARD ASSEMBLY is placed inside.




Fig.3-2-3

3.2.4 ASSEMBLY/DISASSEMBLY OF [13] OP BLOCK ASSEMBLY/CCD BOARD ASSEMBLY

●Precautions

- (1) Take care in handling the CCD IMAGE SENSOR, OPTICAL LPF and lens components when performing maintenance etc., especially with regard to surface contamination, attached dust or scratching. If fingerprints are present on the surface they should be wiped away using either a silicon paper, clean chamois or the cleaning cloth.
- (2) The CCD IMAGE SENSOR may have been shipped with a protective sheet attached to the transmitting glass. When replacing the CCD IMAGE SENSOR, do not peel off this sheet from the new part until immediately before it is mounted in the OP BLOCK ASSEMBLY.

●Disassembly of OP BLOCK ASSEMBLY / CCD BOARD ASSEMBLY

- (1) Unsolder the fourteen soldered points (SD13a) of the CCD BOARD ASSEMBLY.

NOTE13a:

Be careful in handling as there are only the OPTICAL LPF and the SHEET stored inside the OP BLOCK ASSY when the CCD BASE ASSY is removed.

NOTE13b:

Replace the CCD IMAGE SENSOR as a CCD BASE ASSEMBLY, not as a single part replacement.

- (2) Remove the two screws (1, 2), and then remove the CCD BOARD ASSEMBLY and the CCD BASE ASSEMBLY.

●Assembly of OP BLOCK ASSEMBLY / CCD BOARD ASSEMBLY

- (1) Set the OPTICAL LPF first, and then the SHEET to the OP BLOCK ASSEMBLY.

NOTE13c:

Pay careful attention to the orientation of the OPTICAL LPF.

- (2) Attach the CCD BASE ASSEMBLY first then the CCD BOARD ASSEMBLY so that the SHEET stays in place, and tighten with the two screws (1, 2).
- (3) Solder the 14 points (SD13a) on the CCD BOARD ASSEMBLY.

●Replacement of service repair parts

The service repair parts for the OP BLOCK ASSEMBLY are as listed below.

Before replacement of these parts, remove the BRACKET (OP BLOCK ASSEMBLY) as required.

Take special care not to disconnect any of the FPC wires or cause any damage due to soldering (excessive heating).

- (1) FOCUS MOTOR UNIT
- (2) ZOOM MOTOR UNIT
- (3) AUTO IRIS UNIT

NOTE 13d:

When replacing the FOCUS MOTOR UNIT or the ZOOM MOTOR UNIT, solder the FPC at a space of about 0.5 mm above the terminal pin.

NOTE 13e:

The AUTO IRIS UNIT includes the FPC ASSEMBLY and two sensors.




Fig.3-2-4

3.2.5 ASSEMBLY/DISASSEMBLY OF [9] VF ASSEMBLY

●Before disassembly

As the VF ASSEMBLY has complicated structure, do not disassemble if not needed.

When assembling, be careful to prevent dust or any foreign materials entering inside, and avoid soils on both the LENS and the SHEET.

●Disassembly procedure

- (1) Remove the screw (1), and then remove the KNOB (SWITCH).
- (2) Remove the screw (2), and remove the BKT.(COVER).
- (3) Pull out the CASE(VF) from the VF ASSY, remove the screw (3), and then remove the EYE CUP.
- (4) Remove the two screws (4, 5), and then remove the COVER(EYE CUP).

NOTE9a:

Do not remove the COVER(EYE CUP) if not needed as the CASE(VF) can be removed without removing the COVER(EYE CUP).

- (5) Peel off the FPC, and then remove the CASE(VF).

NOTE9b:

During the procedure, be careful in handling the FPC.

- (6) Set the LEVER(VF) to the TRIANGLE MARK(▽) of the CASE(VF), and then remove the LENS ASSY.

NOTE9c:

During the procedure, be careful in handling the parts. Pay special attention not to damage, soil, or leave fingerprints on the surface.

NOTE9d:

After attaching the LENS ASSY, rotate the LEVER(VF) counterclockwise to check the smooth sliding operation of the LENS ASSY.

- (7) Press hooks (L9c,d) on both sides of the HOLDER(LCD) to remove the LCD SA from the CASE(VF).

NOTE9e:

During the procedure, be careful not to damage the VF SW.

NOTE9f:

Refer to the Fig.(VF2) for the disassembly of the LCD SA, and disassemble the LCD SA if necessary. During the procedure, be careful to prevent dust or any foreign materials entering inside.

- (8) Remove the FPC from the connector (CN9), and then remove the VF BOARD ASSY.

NOTE9g:

During the procedure, be careful not to damage the parts.




Fig.VF1

*:0.069N・m(0.7kgf・cm)






Fig.VF2

SECTION 4 ADJUSTMENT

4.1 PREPARATION

4.1.1 Precaution

Camera system and deck system of this model are specially adjusted by using PC.

However, if parts such as the following are replaced, an adjustment is required. The adjustment must be performed in a Service Center equipped with the concerned facilities.

- EEP ROM (IC1005 of MAIN board)
- OP BLOCK ASSEMBLY



















In the event of malfunction with electrical circuits, first find a defective portion with the aid of proper test instruments as shown in the following electrical adjustment procedure, and then commence necessary repair/ replacement/adjustment.

- In observing chip TP, use IC clips, etc. to avoid any stress. Prior to replacement of chip parts (especially IC), remove the solder completely to prevent peeling of the pattern.
- Use a patch cord if necessary. As for a patch cord, see the BOARD INTERCONNECTIONS.
- Since connectors are fragile, carefully handle them in disconnecting and connecting the FPC.

4.1.2 REQUIRED TEST EQUIPMENT

- Personal computer (for Windows)
- Color TV monitor
- Oscilloscope (dual-trace type, observable 100MHz or higher frequency). The one observable 300 MHz or higher frequency is recommended.
- Digital voltmeter
- DC power supply or AC adapter
- Frequency counter (with threshold level adjuster)

4.1.3 TOOLS REQUIRED FOR ADJUSTMENT

Torque Driver YTU94088	Bit YTU94088-003	Tweezers P-895
		
Chip IC Replacement Jig PTS40844-2	Cleaning Cloth KSMM-01	Guide Driver YTU94148A-1
		
INF Adjustment Lens YTU92001B	INF Adjustment Lens Holder YTU94087	Mini Stand YTU93108
		
Light box Assembly YTU93096A	Gray Scale Chart YTU94133A	Color Bar Chart YTU94133C
		
Alignment Tape MC-1	Service Support System YTU94057-92	PC Cable QAM0099-002
		
Communication Cable YTU93111		Jig Connector Cable YTU93106B
		
Conversion Connector YTU94145K-20		
		

- **Torque driver**
Be sure to use to fastening the mechanism and exterior parts because those parts must strictly be controlled for tightening torque.
- **Bit**
This bit is slightly longer than those set in conventional torque drivers.
- **Tweezers**
To be used for removing and installing parts and wires.

- **Chip IC replacement jig**
To be used for adjustment of the camera system.
- **Cleaning cloth**
Recommended the Cleaning cloth to wipe down the video heads, mechanism (tape transport system), optical lens surface.
- **Guide driver**
To be used to turn the guide roller to adjustment of the linearity of playback envelope.
- **INF adjustment lens**
To be used for adjustment of the camera system. For the usage of the INF adjustment lens, refer to the Service Bulletin No. YA-SB-10035.
- **INF adjustment lens holder**
To be used together with the Camera stand for operating the Videocamera in the stripped-down condition such as the status without the exterior parts or for using commodities that are not yet conformable to the interchangeable ring. For the usage of the INF lens holder, refer to the Service Bulletin No. YA-SB-10035.
- **Mini stand**
To be used together with the INF adjustment lens holder. For the usage of the Mini stand, refer to the Service Bulletin No. YA-SB-10035.
- **Light box assembly**
To be used for adjustment of the camera system. For the usage of the Light box assembly, refer to the Service Bulletin No. YA-SB-10035.
- **Gray scale chart**
To be used for adjustment of the camera system. For the usage of the INF adjustment lens, refer to the Service Bulletin No. YA-SB-10035.
- **Color bar chart**
To be used for adjustment of the camera system. For the usage of the INF adjustment lens, refer to the Service Bulletin No. YA-SB-10035.
- **Alignment tape**
To be used for check and adjustment of interchangeability of the mechanism.
- **Service support system**
To be used for adjustment with a personal computer. Software can be downloaded also from JS-net.
- **PC cable**
To be used to connect the Videocamera and a personal computer with each other when a personal computer issued for adjustment.
- **Communication cable**
Connect the Communication cable between the PC cable and Jig connector cable when performing a PC adjustment.
- **Jig connector cable**
Connected to JIG CONNECTOR of the main board and used for electrical adjustment, etc.
- **Conversion connector**
Conversion connector is used to convert the connector part of the JIG connector cable.

4.2 JIG CONNECTOR CABLE CONNECTION

4.2.1 CAUTIONS

- (1) Only 9 of 30pins of JIG CONNECTOR CABLE(PN:YTU93106B) are extended with wires. Additional 5pins (3,6,7,11and18) need to be soldered and extended with the wires for adjustment and checking.

See Fig. 4-2-1 for details.




Fig.4-2-1

■ Connection procedure




Fig.4-2-2

■ Jig connector diagrams




Fig.4-2-3

■ Conversion Connector




Fig.4-2-4

4.3 MECHANISM COMPATIBILITY ADJUSTMENT

4.3.1 Tape pattern adjustment

NOTE:

Prior to the adjustment, remove the COVER (ADJ).

- (1) Play back the compatibility adjustment tape.
- (2) While triggering the HID, observe the waveform of ENV_OUT.
- (3) Set the manual tracking mode (ATF OFF).
- (4) Confirm that the waveform is entirely parallel and straight, and free from remarkable level-down, through the tracking operation.
Make the confirmation as follows if necessary.
- (5) If level-down is observed on the left hand side of the waveform, straighten the level by turning the GUIDE ROLLER (SUP).
If level-down is observed on the right hand side of the waveform, straighten the level by turning the GUIDE ROLLER (TU).
- (6) After the adjustment, try the unloading motion once, and confirm that the waveform is flat when the tape has been played back again.
- (7) Play back the self-recording.
- (8) Confirm that the waveform is flat.




Fig.4-3-1




Fig.4-3-2

4.4 ELECTRICAL ADJUSTMENT

Electrical adjustment is performed by using a personal computer and software for SERVICE SUPPORT SYSTEM. Read README.TXT file to use the software properly.

As for the connection of cables, see "4.2 JIG CONNECTOR CABLE CONNECTION".

SECTION 5 TROUBLE SHOOTING

5.1 SERVICE NOTE

CABINET PARTS AND ELECTRICAL PARTS(1)

Symbol No.	[1]																[8]							
Removing order of screw	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	[5]				[6]			
Place to stick screw	**	**	**	**	**	**	**	*					**	**	**	**	-	-	-	-	17	18	19	20
Reference drawing (Fig.No.)	FA1-1																FA2-1				FA2-4			
Screw tightening torque	a																b				FA3			
																					FA4			

CABINET PARTS AND ELECTRICAL PARTS(2)

Symbol No.	[9]																[16]											
Removing order of screw	27	28	29	30	31	32	33	34	35	-	36	37	38	39	40	41	42	43	[15]				[16]					
Place to stick screw		**	*		*	**	*	*	*	*	*	*	*	*	*	*	*	*										
Reference drawing (Fig.No.)	FA5				FA6				FA7				FA8				FA9				FA10							
Screw tightening torque																	a								c			

[4]MONITOR ASSY [13]OP BLOCK ASSY/CCD BOARD ASSY

Symbol No.	[4]									[13]								
Removing order of screw	1	2	3	4						1	2	3	4	5	6	7	8	9
Place to stick screw	**	**	*	*														
Reference drawing (Fig.No.)	3-2-3									3-2-4								
Screw tightening torque	a									d								
										a								

[9]VF ASSY

Symbol No.	[9]						[9]					
Removing order of screw	1	2	3	4	5	6						
Place to stick screw	**	*	*	*	*	*						
Reference drawing (Fig.No.)	VF1						VF2					
Screw tightening torque							e					

NOTE:

- 1) * and ** (This mark shows where to attach the screws) : Do not reuse the screws because the screw lock bond was applied to prevent the screws from loosening.
Prepare the specified screws and use them in place of the removed screws.
- 2) Tightening torque for the screws
 - There are setting limits of the torque value for the torque driver. If the value exceeds the setting value, take it as a rough measurement (reference value), and tighten the screw manually.
 - The specified torque value is a recommended value of the initial assembly. Therefore, set the value below the specified torque value in the assembling procedure. Be careful not to break either the screws or the screw holes.


a : 0.098N·m (1.0kgf·cm) b : 0.196N·m (2.0kgf·cm) c : 0.088N·m (0.9kgf·cm) d : 0.147N·m (1.5kgf·cm) e : 0.069N·m (0.7kgf·cm)

5.2 EMERGENCY DISPLAY


Whenever some abnormal signal is input to the syscon CPU, an error number (E01 and E04, as an example) is displayed on the LCD monitor or (in the electronic view finder). In every error status, such the message as shown below alter nately appear over and over.

- In an emergency mode, all operations except turning on/off the POWER switch are ineffectual.

Example (in case of the error number E01):



Example (in case of the error number E04):



LCD display	Emergency mode	Details	Possible cause																		
E01	LOADING	In the case the encoder position is not shifted to the next point though the loading motor has rotated in the loading direction for 4 seconds or more. This error is defined as [E01].	1. The mechanism is locked during mode shift. 2. The mechanism is locked at the mechanism loading end, because the encoder position is skipped during mechanism mode shift. 3. No power is supplied to the loading MDA.																		
E02	UNLOADING	In the case the encoder position is not shifted to the next point though the loading motor has rotated in the unloading direction for 4 seconds or more. This error is defined as [E02].	1. The mechanism is locked during mode shift. 2. The mechanism is locked at the mechanism loading end, because the encoder position is skipped during mechanism mode shift.																		
E03	REEL FG(TU & SUP)	In the case no REEL FG is produced for seconds shown in the table below or more in the capstan rotation mode after loading was complete, the mechanism mode is shifted to STOP with the pinch roller set off. This error is defined as [E03].However, no REEL EMG is detected in the SLW/ STILL mode. <table><tr><td></td><td>REEL(SUP)</td><td>REEL(TU)</td></tr><tr><td>PB/REC</td><td>3 SEC</td><td>3 SEC</td></tr><tr><td>S-FWD</td><td>3 SEC</td><td>0.3 SEC</td></tr><tr><td>S-REW</td><td>0.3 SEC</td><td>3 SEC</td></tr><tr><td>FF</td><td>3 SEC</td><td>0.1 SEC</td></tr><tr><td>REW</td><td>0.1 SEC</td><td>3 SEC</td></tr></table>		REEL(SUP)	REEL(TU)	PB/REC	3 SEC	3 SEC	S-FWD	3 SEC	0.3 SEC	S-REW	0.3 SEC	3 SEC	FF	3 SEC	0.1 SEC	REW	0.1 SEC	3 SEC	1. The idler gear does not engage with the reel disk well. 2. Though the idler gear and reel disk are engaged with each other, the tape is not wound because of overload to the mechanism. 3. No FG pulse is output from the reel sensor. 4. No power is supplied to the reel sensor. 5. Tape transport operation takes place with a cassette having no tape inside. 6. The tape slackens and no pulse is produced until the slack is taken up and the tape comes into the normal status.
	REEL(SUP)	REEL(TU)																			
PB/REC	3 SEC	3 SEC																			
S-FWD	3 SEC	0.3 SEC																			
S-REW	0.3 SEC	3 SEC																			
FF	3 SEC	0.1 SEC																			
REW	0.1 SEC	3 SEC																			
E04	DRUM FG	In the case there is no DRUM FG input in the drum rotation mode for 4 seconds or more. This error is defined as [E04], and the mechanism mode is shifted to STOP with the pinch roller set off.	1. The drum cannot be started or drum rotation is stopped because tape transport load is too high. 1) Tape tension is extremely high. 2) The tape is damaged or soiled with grease, etc. 2. The DRUM FG signal is not received by the syscon CPU. 1) Disconnection in the middle of the signal line. 2) Failure of the DRUM FG pulse generator (hall element). 3. No drum control voltage is supplied to the MDA. 4. No power is supplied to the DRUM MDA.																		
E05	-	-	-																		
E06	CAPSTAN FG	In the case no CAPSTAN FG is produced in the capstan rotation mode for 2 seconds or more. This error is defined as [E06], and the mechanism mode is shifted to STOP with the pinch roller set off.However, no CAPSTAN EMG is detected in the STILL/FF/REW mode.	1. The CAPSTAN FG signal is not received by the syscon CPU. 1) Disconnection in the middle of the signal line. 2) Failure of the CAPSTAN FG pulse generator (MR element). 2. No capstan control voltage is supplied to the MDA. 3. The capstan cannot be started or capstan rotation is stopped because tape transport load is too high. 1) Tape tension is extremely high. (Mechanical locking) 2) The tape is damaged or soiled with grease, etc. (Tape tangling occurs, etc.)																		

Fig.5-2-1



Victor Company of Japan, Limited
Camcorder Category 12, 3-chome, Moriya-cho, kanagawa-ku, Yokohama, kanagawa-prefecture, 221-8528, Japan



PARTS LIST

SAFETY PRECAUTION

Parts identified by the $\triangle$ symbol are critical for safety. Replace only with specified part numbers.



BEWARE OF BOGUS PARTS

Parts that do not meet specifications may cause trouble in regard to safety and performance. We recommend that genuine JVC parts be used.



1. EXPLODED VIEW


1.1 FINAL ASSEMBLY<M1>


The instruction manual to be provided with this product will differ according to the destination.




MODEL	MARK
GR-D370UC	A
GR-D370US	B
GR-D371US	C
GR-D375UC	D
GR-D375US	E
GR-D390UC	F
GR-D390US	G
GR-D395US	H
GR-D396US	J







1.2 MECHANISM ASSEMBLY<M2>




Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-JB	AA
Oil	YTU94027	BB
Grease (HANARL)	RX-410R	CC


NOTE1: The section marked in AA, BB and CC indicate lubrication and greasing areas.

1.3 VF ASSEMBLY <M3>

700



1.4 PACKING AND ACCESSORY ASSEMBLY <M5>



MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D370UC	A	GR-D375UC	D	GR-D390US	G
GR-D370US	B	GR-D375US	E	GR-D395US	H
GR-D371US	C	GR-D390UC	F	GR-D396US	J

2. PARTS LIST

FINAL ASSEMBLY <M1>

△ Symbol No.	Part No.	Part Name	Description	Local
101	LY35130-001D	FRAME ASSY		
101A	LY45033-001B	BUSH	(x4)	
101B	LY35129-001B	TRIPOD (BASE)		
101C	LY30031-0D4A	SPECIAL SCREW	FRM-TRIP	
104	LY21444-001H	MAIN BKT ASSY		
104A	LY45170-001C	TENSION SPRING		
104B	LY30002-074A	COMPRESSION SPRING		
106	LY35271-003C	LOWER CASE ASSY		
106A	LY45172-003A	STICKER(L)		
107	LY21320-001B	GRIP BELT		
108	LY45121-001A	BKT (GBELT)		
109	LY21431-001B	POWER UNIT		
△ 110	LY35115-001E	REAR COVER ASSY		
110A	LY35137-001A	KNOB (BATT.)		
110B	LY30002-068A	COMPRESSION SPRING		
111	LY35131-001A	KNOB (EJECT)		
112	LY21446-001E	CASS COVER		
113	LY30032-002A	SPECIAL SCREW	FRM-MECHA(x4)	
114	LY30031-0K7A	SPECIAL SCREW	M.PWB-FRM	
116	LY30031-0H5A	SPECIAL SCREW	FRM-M.BKT(x3)	
117	LY30031-0K7A	SPECIAL SCREW	R.PWB-BKT	
118	LY30031-0L8B	SPECIAL SCREW	POWER UNIT(x3)	
119	LY30031-0H5A	SPECIAL SCREW	LOWER-MBKT(x2)	
120	LY30031-0A3A	SPECIAL SCREW	LOWER-REAR	
121	LY30031-0D4A	SPECIAL SCREW	REAR-M.BKT	
122	LY30031-0D5A	SPECIAL SCREW	REAR-M.BKT	
124	LY30031-0A3A	SPECIAL SCREW	LOWER-VF	
125	LY30031-0H5A	SPECIAL SCREW	CASS COVER(x4)	
126	LY30031-0D5A	SPECIAL SCREW	FRONT-MBKT(x2)	
127	LY30031-0H5A	SPECIAL SCREW	FRONT-MBKT	
128	LY30031-0D5A	SPECIAL SCREW	UPPER-TRI(x3)	
129	LY30031-0A3A	SPECIAL SCREW	REAR-UPPER(x2)	
130	LY30031-0K7A	SPECIAL SCREW	DV JACK	
131	LY30031-0D5A	SPECIAL SCREW	LOWER-ZOOM	
132	LY30031-0H5A	SPECIAL SCREW	VF-M.BKT	
201	LY35149-001C	COVER (JIG)		
202	LY35150-001A	COVER (ADJ)		
203	LY35138-001B	COVER (JACK)		
250	QAM0366-002	MEMORY CARD	MMC 8MB* F,G	
△ 300	LY35154-010E	UPPER ASSY	A,B,D,E,F,G,H,J	
△ 300	LY35154-023B	UPPER ASSY	C	
△ 300	or UU06D110E	UPPER UNIT ASSY	A,B,D,E,F,G,H,J	
△ 300	or UU06D123B	UPPER UNIT ASSY	C	
301	LY21452-001B	LCD CASE		
302	LY45123-001A	SHEET(M.DIFF)		
303	LY35160-001A	S.CASE (MONI)		
304	LY45125-001A	SHEET(M.REF)		
305	LY35155-009A	MONITOR COVER ASSY		
305A	LY45126-001B	JVC MARK		
305B	LY45156-008A	STICKER		
306	LY21450-001D	MONITOR CASE		
307	QLD0357-001	LCD MODULE		
308	LY45124-001A	LIGHT GUIDE		
310	LY45152-001A	SHEET(BEF)		
311	LY30031-0K7A	SPECIAL SCREW	MONI.PWB	
312	LY30031-0K7A	SPECIAL SCREW	MONI.CASE(x2)	
313	LY35157-001B	HINGE ASSY		
314	LY35159-001B	HINGE COVER(L)		
315	LY35158-001B	HINGE COVER(U)		
316	LY42355-001A	P.C.MAGNET		
317	QAL0784-001	FPC	MONI-FPC	
318	LY30031-0A3A	SPECIAL SCREW	HINGE	
△ 319	LY21439-004E	UPPER CASE ASSY	A,B,D,E,F,G,H,J	
△ 319	LY21439-010B	UPPER CASE ASSY	C	
320	LY21432-001C	ZOOM UNIT		
321	QAS0284-002	SPEAKER		
322	LY35146-001A	BRACKET(HINGE)		
323	LY35147-001A	COVER (HINGE)		
326	LY30031-003A	SPECIAL SCREW	ZOOM UNIT(x3)	
328	LY30031-054A	SPECIAL SCREW	MONI HINGE(x2)	
329	LY30031-0H5A	SPECIAL SCREW	CVR HINGE(x2)	
330	LY30031-003A	SPECIAL SCREW	OPEPWB-UPP(x4)	
331	LY30031-0H5A	SPECIAL SCREW	OPEPWB-BKT	
350	LY35148-001B	KNOB (SLIDE)		

△ Symbol No.	Part No.	Part Name	Description	Local
399	LY35387-001A	EARTH PLATE		
500	LY35210-003A	FRONT ASSY		
500	or FU06D103A	FRONT UNIT ASSY		
501	LY21447-003A	FRONT COVER		
502	LY35133-001B	HOOD (SCREW)		
503	LY35132-001B	COVER (HOOD)		
504	LY35134-001B	SENSOR HOLDER		
505	LY34598-001A	MIC		
506	LY35135-001A	PLATE (MIC)		
507	LY30031-003A	SPECIAL SCREW	HOOD SCREW(x4)	
508	LY30031-003A	SPECIAL SCREW	PLATE MIC	
509	LY30030-0D3A	SPACER(A)		
601	LY35128-001B	CUSHION (OP)		
602	LY35161-003A	OP BLOCK ASSY		
602A	PTY35161-002	FOCUS MOTOR UNIT		
602B	PTY35161-001	ZOOM MOTOR UNIT		
602C	PTY35161-306	IRIS MOTOR UNIT		
602D	PTY35161-535	SCREW	M1.7 x 3.5(x7)	
603	LYH30655-051A	CCD BASE ASSY		
604	LY45175-001A	SHEET		
605	LY45144-001A	OPTICAL LPF		
606	LY30031-0M3A	SPECIAL SCREW	(x2)	

*NOTE:

DATA FILE is not contained in MEMORY CARD of the service part.

MECHANISM ASSEMBLY <M2>

△ Symbol No.	Part No.	Part Name	Description	Local
900	YMB0051C	MECHA(B)ASSY		
900A	YMA0051B	MECHA(A)ASSY		
901	LY10525-001F	MAIN DECK ASSY		
902	LY34335-001B	LOADING GEAR 1		
903	LY34338-001A	BELT GUIDE		
904	LY34229-001A	MINI SCREW	(x16)	
905	LY44973-001B	SLIDE COLLAR 1		
906	LY44974-001B	SLIDE COLLAR 2		
907	QSW1116-002	ROTARY ENCODER		
908	LY21263-001B	MAIN CAM		
909	LY34319-001A	CONNECT GEAR		
910	LY34320-001A	SUB CAM		
911	LY34321-001B	PRESS ARM ASSY		
912	LY21264-001C	GEAR COVER		
913	LY34315-001E	M.BRACKET ASSY		
914	LY34337-001A	CENTER GEAR		
915	LY34336-001A	REEL PULLEY		
916	QAR0338-002	CAPSTAN MOTOR		
917	LY21270-001A	T5 CATCHER		
918	LY21266-001G	GUIDE RAIL ASSY		
919	LY34325-001B	DRIVE ARM ASSY		
920	LY10530-001E	DRUM BASE		
921	LY34326-001E	T.C.PLATE ASSY		
922	LY21271-005A	SLIDE DECK ASSY		
923	LY34345-001A	P.R.ARM ASSY		
924	LY44764-001B	TEN.SPRING(P.R)		
925	LY34348-001A	BRAKE PLATE		
926	LY34349-001D	REEL DISK ASSY		
927	LY34349-002B	REEL DISK ASSY		
928	LY34342-001A	GUIDE PLATE		
929	LY34340-001A	SLIDE GUIDE PLT		
930	LY34229-005A	MINI SCREW		
931	LY34358-001G	S1 ARM ASSY		
932	LY21273-001K	T.ARM ASSY		
933	LY43675-007A	MINI SCREW		
934	LY34355-001B	IDLER ARM ASSY		
935	LY34343-001B	T5 ARM ASSY		
936	LY34341-001B	CASSETTE GUIDE		
937	LY34365-001E	REEL COVER ASSY		
938	LY10531-001K	HOUSING ASSY		
939	LY44734-001B	COMP.SPRING		
940	LY34314-001A	G.ROLLER(S)ASSY		
941	LY45076-001A	TRUSTER SCREW		
982	YDV2104H-CX	DRUM ASSY		
983	LY10599-001A	PROTECTOR		

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D370UC	A	GR-D375UC	D	GR-D390US	G
GR-D370US	B	GR-D375US	E	GR-D395US	H
GR-D371US	C	GR-D390UC	F	GR-D396US	J

△ Symbol No.	Part No.	Part Name	Description	Local
984	LY34229-006A	MINI SCREW		
995	LY34229-010A	MINI SCREW		
996	LY34676-002A	MOTOR FPC ASSY		
997	LY34318-001A	WORM WHEEL		
998	LY44890-001A	LABEL(HOUSING)		
999	LY34229-006A	MINI SCREW	(x3)	

VF ASSEMBLY <M3>

△ Symbol No.	Part No.	Part Name	Description	Local
700	LY35117-001A	VF ASSY		
700	or VU06D101A	VF UNIT ASSY		
701	LY21442-001C	HOLDER (LCD)		
702	LY45116-001A	CUSHION (1)		
703	LY45118-001A	SHEET (POLA)	(x2)	
704	LY45119-001A	SHEET (DIFF.)		
705	LY35123-001B	CASE (B.LIGHT)		
706	LY45117-001A	CUSHION (2)		
707	LY35124-001A	STOPPER (POLA)		
708	LY21441-001E	CASE (VF)		
709	LY45114-001A	LENS ASSY		
710	LY35121-001B	LEVER (VF)		
712	LY35118-001C	BRACKET(COVER)		
713	LY21440-001E	COVER (SLIDE)		
714	LY35126-001C	CLICK PLATE		
715	LY35119-001C	EYE CUP		
716	QLD0363-001	LCD MODULE		
718	QAL0783-001	FPC	VF FPC	
719	LY35169-001D	COVER (EYE CUP)		
720	LY35168-001C	KNOB (SWITCH)		
721	LY30031-0H5A	SPECIAL SCREW		
722	LY30031-003A	SPECIAL SCREW	CVREYECUP(x2)	
723	LY30031-057A	SPECIAL SCREW	EYECUP	
724	LY30031-0H5A	SPECIAL SCREW	BKT.COVER	
725	LY30031-0K7A	SPECIAL SCREW	KNOB SW	

PACKING AND ACCESSORY ASSEMBLY <M5>

△ Symbol No.	Part No.	Part Name	Description	Local
001	LY34452-001A	POLY BAG	DOCUMENT	
△ 002	LYT1521-001A	INST BOOK(EN.SP)	(ENGLISH/SPANISH)	H
△ 002	LYT1522-001A	INST BOOK(EN.SP)	(ENGLISH/SPANISH)	B
△ 002	LYT1523-001A	INST BOOK(EN.FR)	(ENGLISH/FRENCH)	A
△ 002	LYT1528-001A	INST BOOK(EN.SP)	(ENGLISH/SPANISH)	G
△ 002	LYT1529-001A	INST BOOK(EN.FR)	(ENGLISH/FRENCH)	F
△ 002	LYT1530-001A	INST BOOK(EN.SP)	(ENGLISH/SPANISH)	E
△ 002	LYT1531-001A	INST BOOK(EN.FR)	(ENGLISH/FRENCH)	D
△ 002	LYT1589-001A	INST BOOK(EN.SP)	(ENGLISH/SPANISH)	C
△ 002	LYT1590-001A	INST BOOK(EN.SP)	(ENGLISH/SPANISH)	J
004	-----	WARRANTY CARD	BT-51005-9	
005	BT-51034-2	REGISTRATION CARD		B,C,E,G,H,J
006	-----	WARRANTY CARD	BT-52006-2	A,D,F
050	LYT1520-001A	INST BOOK(SOFT.EN.SP)	(SOFT.ENGLISH/SPANISH)	B,C,E,H,J
050	LYT1520-002A	INST BOOK(SOFT.EN.FR)	(SOFT.ENGLISH/FRENCH)	A,D
050	LYT1532-001A	INST BOOK(SOFT.EN.SP)	(SOFT.ENGLISH/SPANISH)	G
050	LYT1532-002A	INST BOOK(SOFT.EN.FR)	(SOFT.ENGLISH/FRENCH)	F
051	LY35273-005A	CD ROM ASSY		A,B,C,D,E,H,J
051	LY35273-006A	CD ROM ASSY		F,G
099	LYT1521-002A	SHEET(CORR.)		H
099	LYT1522-002A	SHEET(CORR.)		B
099	LYT1590-002A	SHEET(CORR.)		E,J
801	LY30023-003A	POLY BAG		
802	LY35151-007A	PACKING CASE	PRODUCTION	A,B,C,D,E,H,J
802	LY35151-010A	PACKING CASE	PRODUCTION	F,G
803	LY35152-001B	CUSHION		
804	LY45161-002A	LABEL		
805	QPA02503505P	POLY BAG	ACC.25cm x 35cm	
806	QAM0507-001	A/V CABLE		
△ 807	LY21103-001D	AC ADAPTER	AP-V14U	
△ 807	or LY21456-001A	AC ADAPTER	AP-V18U	
808	LY34194-001D	HOOD CAP ASSY(N)		

△ Symbol No.	Part No.	Part Name	Description	Local
△ 809	LY34648-002A	BATTERY PACK	BN-VF714U	H
△ 809	LY34647-002B	BATTERY PACK	BN-VF707U	A,B,C,D,E,F,G
△ 809	LY34647-002B	BATTERY PACK	BN-VF707U(x2)	J
810	LY21397-002A	SHOULDER STRAP		
850	QAM0719-001	USB CABLE	USB	
851	QQR0491-002	FERRITE CORE	USB	
852	LY21186-002A	REMOTE CTL UNIT	RM-V720U	C,D,E,F,G,H,J

MAIN BOARD ASSEMBLY <01>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	LYA10065-01B	MAIN BOARD ASSY		A,B
PW1	LYA10065-02B	MAIN BOARD ASSY		C,D,E,F,G,H,J
IC1001	or MN103SF66RBA	IC(MICRO C ROM)	FLASH(AP)	
IC1001	or MN103S97NBA	IC(MICRO C ROM)	MP	
IC1002	BU3095-0LFV-X	IC	OSD US/KR	
IC1004	NJU7108F3-X	IC		
IC1004	or TC75S56FU-X	IC		
IC1005	M95320-WDW6-X	IC		
IC1005	or BR25C320FV-W-X	IC		
IC1006	RS5C314-X	IC		
IC1007	S-80823CNNB-G-W	IC		
IC1008	KSM-2003SN2E	IR DETECT UNIT	IRU	C,D,E,F,G,H,J
IC1601	BD6637KV	IC	MDA 64PIN	
IC1701	BA10358FVM-W	IC	REELAMP5V	
IC1702	NJM2407R-W	IC	REELSMT	
IC2201	AK4660VQ	IC	48P0.5	
IC3001	JCY0205-3	IC	PARAGON IC	
IC3004	BH2226FV-X	IC	EVRDAC	
IC3201	JCP8055FP-2	IC		
IC3501	JCY0132	IC		
IC3702	NJM2562F1-X	IC		
IC4201	LY35174-001A	IC	(SERVICE)	
IC4901	LM324PW-X	IC		
IC4902	BA10358FVM-W	IC		
IC4903	NJM3414AV-X	IC		
IC4904	MM6564XFBE-X	IC		
IC4951	AN41902A	IC		
IC6001	FA7737F	IC		
IC7801	LV4141W-E-X	IC		
IC8001	TMS320DSC24GHKL	IC	DSC24	
IC8002	K4S643232H-UC60	IC	64MSDRAM	
IC8003	MR27T3202L057LA	IC(MICRO C ROM)	MP P2ROM	
IC8003	or SG32A90BFIR4C31	IC(MICRO C ROM)	AP FLASH	
IC8005	MM3141JN-X	IC	REG 1.8V	
Q1001	DTA114EE-X	DIGI TRANSISTOR		
Q1001	or BCR183T-X	DIGI TRANSISTOR		
Q1001	or KRA302E-X	DIGI TRANSISTOR		
Q1001	or RT1P141U-X	DIGI TRANSISTOR		
Q1001	or PDTA114EE-X	DIGI TRANSISTOR		
Q1002	DTA143XE-X	DIGI TRANSISTOR		
Q1003	DTA143XE-X	DIGI TRANSISTOR		
Q1004	DTC143XE-X	DIGI TRANSISTOR		
Q1005	DTC143XE-X	DIGI TRANSISTOR		
Q1005	or UN921FJ-X	DIGI TRANSISTOR		
Q1005	or KRC419E-X	DIGI TRANSISTOR		
Q1005	or RT1N432U-X	DIGI TRANSISTOR		
Q1006	2SC4617/QR/-X	TRANSISTOR		
Q1006	or BC847BT-X	TRANSISTOR		
Q1006	or 2SD2216J/QR/-X	TRANSISTOR		
Q1006	or 2SC5383/E/-X	TRANSISTOR		
Q1006	or 2SC4738/YG/-X	TRANSISTOR		
Q1007	DTC124EE-X	DIGI TRANSISTOR		
Q1007	or BCR141T-X	DIGI TRANSISTOR		
Q1007	or KRC403E-X	DIGI TRANSISTOR		
Q1007	or RT1N241U-X	DIGI TRANSISTOR		
Q1007	or PDTC124EE-X	DIGI TRANSISTOR		
Q1008	UMZ1N-W	PAIR TRANSISTOR		
Q1008	or PUMZ1-W	PAIR TRANSISTOR		
Q1008	or XP4601-W	TRANSISTOR		
Q1601	UMC3N-W	DIGI TRANSISTOR	LD ON	
Q2403	2SC4617/QR/-X	TRANSISTOR		
Q2403	or BC847BT-X	TRANSISTOR		

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D370UC	A	GR-D375UC	D	GR-D390US	G
GR-D370US	B	GR-D375US	E	GR-D395US	H
GR-D371US	C	GR-D390UC	F	GR-D396US	J

△ Symbol No.	Part No.	Part Name	Description	Local
Q2403	or 2SD2216J/QR/-X	TRANSISTOR		
Q2403	or 2SC5383/E/-X	TRANSISTOR		
Q2403	or 2SC4738/YG/-X	TRANSISTOR		
Q3001	2SC4617/QR/-X	TRANSISTOR	AREG3V	
Q3001	or BC847BT-X	TRANSISTOR	AREG3V	
Q3001	or 2SD2216J/QR/-X	TRANSISTOR	AREG3V	
Q3001	or 2SC5383/E/-X	TRANSISTOR	AREG3V	
Q3001	or 2SC4738/YG/-X	TRANSISTOR	AREG3V	
Q3002	HN1B01FU/G/-X	PAIR TRANSISTOR		
Q3003	HN1B01FU/G/-X	PAIR TRANSISTOR		
Q4901	2SC4617/QR/-X	TRANSISTOR		
Q4901	or BC847BT-X	TRANSISTOR		
Q4901	or 2SD2216J/QR/-X	TRANSISTOR		
Q4901	or 2SC5383/E/-X	TRANSISTOR		
Q4901	or 2SC4738/YG/-X	TRANSISTOR		
Q4902	DTC144EE-X	DIGI TRANSISTOR		
Q4903	2SC4617/RS/-X	TRANSISTOR		
Q4904	2SC4617/RS/-X	TRANSISTOR		
Q4905	DTA144EE-X	DIGI TRANSISTOR		
Q4906	2SA1774/QR/-X	TRANSISTOR		
Q4951	DTC114EE-X	DIGI TRANSISTOR		
Q4951	or UN9211J-X	DIGI TRANSISTOR		
Q4951	or RN1102-X	DIGI TRANSISTOR		
Q4951	or BCR133T-X	DIGI TRANSISTOR		
Q4951	or PDTTC114EE-X	DIGI TRANSISTOR		
Q4981	RPM-22PB	PHOTO TRANSISTOR		
Q6101	US5U29-W	MOS FET		
Q6103	RSR025P03-X	MOS FET		
Q6201	US5U29-W	MOS FET		
Q6301	US5U29-W	MOS FET		
Q6401	US5U29-W	MOS FET		
Q6501	RSR025P03-X	MOS FET		
Q6505	2SA1774/QR/-X	TRANSISTOR	-VE	
Q6505	or BC857BT-X	TRANSISTOR	-VE	
Q6505	or 2SA1989/QR/-X	TRANSISTOR	-VE	
Q6701	RSR025P03-X	MOS FET		
Q6702	RSR025P03-X	MOS FET		
Q6703	RSR025P03-X	MOS FET		
Q7701	PUMX1-W	PAIR TRANSISTOR		
Q7701	or BC847S-X	PAIR TRANSISTOR		
Q7701	or KTC801U/G/-X	PAIR TRANSISTOR		
Q7701	or RT3CLLM/EF/-X	PAIR TRANSISTOR		
Q7702	PUMX1-W	PAIR TRANSISTOR		
Q7702	or BC847S-X	PAIR TRANSISTOR		
Q7702	or KTC801U/G/-X	PAIR TRANSISTOR		
Q7702	or RT3CLLM/EF/-X	PAIR TRANSISTOR		
Q7703	PUMX1-W	PAIR TRANSISTOR		
Q7703	or BC847S-X	PAIR TRANSISTOR		
Q7703	or KTC801U/G/-X	PAIR TRANSISTOR		
Q7703	or RT3CLLM/EF/-X	PAIR TRANSISTOR		
Q7704	UMD3N-W	DIGI TRANSISTOR		
Q7704	or XP4311-W	TRANSISTOR		
Q7704	or RT3T11M-X	DIGI TRANSISTOR		
Q7704	or KRX201U-X	DIGI TRANSISTOR		
Q8002	DTA114EE-X	DIGI TRANSISTOR		
Q8004	EMD2-W	PAIR TRANSISTOR		
D1001	DA221-X	DIODE ARRAY		
D1001	or MA133-X	SI DIODE		
D1001	or KDS221E-X	SI DIODE		
D1003	NSPW500CS/C0TU/	LED		
D1603	DAP222-X	DIODE ARRAY	LD ON	
D1603	or MA132WA-X	SI DIODE		
D3001	RB551V-30-X	SI DIODE	PHYVDD	
D3001	or KDR412-X	SB DIODE	PHYVDD	
D3002	1SV303-X	VARI CAP DIODE	1SV303	
D3004	EC2C01C-TR-X	VARI CAP DIODE	MAIN VCO	
D3005	DAN222-X	SI DIODE		
D3005	or MA132WK-X	SI DIODE		
D3005	or MC2858-X	SI DIODE		
D3005	or 1SS361-X	SI DIODE		
D4201	1SS355-X	SI DIODE		
D4201	or MA111-X	SI DIODE		
D4201	or 1SS352-X	SI DIODE		
△ D6001	RB715W-X	SB DIODE		
D6503	1SS355-X	SI DIODE		
D6503	or MA111-X	SI DIODE		
D6503	or 1SS352-X	SI DIODE		

△ Symbol No.	Part No.	Part Name	Description	Local
D6504	1SS355-X	SI DIODE		
D6504	or MA111-X	SI DIODE		
D6504	or 1SS352-X	SI DIODE		
D6505	1SS355-X	SI DIODE		
D6505	or MA111-X	SI DIODE		
D6505	or 1SS352-X	SI DIODE		
D6506	1SS355-X	SI DIODE		
D6506	or MA111-X	SI DIODE		
D6506	or 1SS352-X	SI DIODE		
D6507	UDZS8.2B-X	Z DIODE		
D6701	RB160M-30-X	SB DIODE		
D6702	RB160M-30-X	SB DIODE		
D6801	RB551V-30-X	SB DIODE		
D6801	or KDR412-X	SB DIODE		
C1001	NDCA1HJ-3R0W	C CAPACITOR	3pF 50V J	
C1002	NDCA1HJ-3R0W	C CAPACITOR	3pF 50V J	
C1003	NDCA1HJ-7R0W	C CAPACITOR	7pF 50V J	
C1004	NBE20JM-226X	TA E CAPACITOR	22uF 6.3V M	
C1005	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1006	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1007	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C1008	NBE20JM-226X	TA E CAPACITOR	22uF 6.3V M	
C1009	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1013	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1018	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C1023	NCBA1EK-682W	C CAPACITOR	6800pF 25V K	
C1024	NCBA1EK-682W	C CAPACITOR	6800pF 25V K	
C1025	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1029	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1030	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1031	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1032	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1033	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1035	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1036	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1038	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1039	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1040	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1044	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1046	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1051	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C1052	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C1053	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C1054	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C1055	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C1601	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1602	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C1603	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C1605	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1606	NCBA1HK-152W	C CAPACITOR	1500pF 50V K	
C1607	NCBA1CK-473W	C CAPACITOR	0.047uF 16V K	
C1614	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C1618	NCBA1HK-222W	C CAPACITOR	2200pF 50V K	
C1619	NCBA1HK-222W	C CAPACITOR	2200pF 50V K	
C1620	NCBA1HK-222W	C CAPACITOR	2200pF 50V K	
C1621	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C1622	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C1623	NCBA1CK-473W	C CAPACITOR	0.047uF 16V K	
C1624	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1625	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C1626	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C1627	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C1628	NCB31CK-224X	C CAPACITOR	0.22uF 16V K	
C1629	NCB21EK-224X	C CAPACITOR	0.22uF 25V K	
C1630	NCB21EK-224X	C CAPACITOR	0.22uF 25V K	
C1631	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C1632	NCB21CK-474X	C CAPACITOR	0.47uF 16V K	
C1633	NCB30JK-474X	C CAPACITOR	0.47uF 6.3V K	
C1637	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C1702	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2201	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2202	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2203	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2204	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2205	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2209	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2210	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D370UC	A	GR-D375UC	D	GR-D390US	G
GR-D370US	B	GR-D375US	E	GR-D395US	H
GR-D371US	C	GR-D390UC	F	GR-D396US	J

△ Symbol No.	Part No.	Part Name	Description	Local
C2213	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2214	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2217	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2218	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2223	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2224	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2402	NCJ20JK-106X-D	C CAPACITOR		
C2403	NCJ20JK-106X-D	C CAPACITOR		
C2404	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2405	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2406	NCJ20JK-106X-D	C CAPACITOR		
C2407	NCJ20JK-106X-D	C CAPACITOR		
C2603	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C2604	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C2605	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C2606	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C2611	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2612	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2613	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2623	NDCA1HJ-100W	C CAPACITOR	10pF 50V J	
C2624	NDCA1HJ-100W	C CAPACITOR	10pF 50V J	
C2655	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C2656	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3002	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3006	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3008	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3010	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3014	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3016	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3017	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3018	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3020	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3021	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3022	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3025	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3026	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3029	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C3030	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C3032	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3033	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3035	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3037	NCB31AK-334X	C CAPACITOR	0.33uF 10V K	
C3039	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3040	NDCA1EJ-221W	C CAPACITOR	220pF 25V J	
C3046	NCB31CK-224X	C CAPACITOR	0.22uF 16V K	
C3049	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3050	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3051	NDCA1HJ-820W	C CAPACITOR	82pF 50V J	
C3052	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3053	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C3054	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3055	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3058	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C3059	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3060	NDCA1EJ-271W	C CAPACITOR	270pF 25V J	
C3062	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3063	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3064	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3065	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3067	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3068	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3071	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3072	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3073	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3078	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3079	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3080	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3202	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3203	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3204	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3205	NBE20JM-476X	TA E CAPACITOR	47uF 6.3V M	
C3206	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3210	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3212	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3213	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3215	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3216	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3504	NCBA1CK-473W	C CAPACITOR	0.047uF 16V K	

△ Symbol No.	Part No.	Part Name	Description	Local
C3505	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C3506	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3507	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3508	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3509	NCJ20JK-106X-D	C CAPACITOR		
C3510	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3511	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3512	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3513	NCJ20JK-106X-D	C CAPACITOR		
C3514	NCBA1CK-473W	C CAPACITOR	0.047uF 16V K	
C3515	NCBA1CK-473W	C CAPACITOR	0.047uF 16V K	
C3516	NCBA1CK-473W	C CAPACITOR	0.047uF 16V K	
C3517	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3518	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3519	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C3520	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3521	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3522	NCB20JM-475X	C CAPACITOR	4.7uF 6.3V M	
C3523	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3524	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3525	NCB20JM-475X	C CAPACITOR	4.7uF 6.3V M	
C3526	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3527	NDCA1EJ-221W	C CAPACITOR	220pF 25V J	
C3710	NBE20GM-226X	TA E CAPACITOR	22uF 4V M	
C3712	NBE40GM-107X	TA E CAPACITOR	100uF 4V M	
C3717	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3718	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4201	NCB11EK-105X	C CAPACITOR	1uF 25V K	
C4202	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4203	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C4204	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C4205	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C4206	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4207	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4208	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C4209	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C4210	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4211	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4212	NBE20JM-476X	TA E CAPACITOR	47uF 6.3V M	
C4213	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4214	NDCA1HJ-9R0W	C CAPACITOR	9pF 50V J	
C4215	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J	
C4216	NCB11CK-475X	C CAPACITOR	4.7uF 6.3V K	
C4217	NBP21CM-106X	TA E CAPACITOR	10uF 16V M	
C4218	NCB11CK-475X	C CAPACITOR	4.7uF 16V K	
C4219	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4220	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4221	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4224	NDCA1HJ-100W	C CAPACITOR	10pF 50V J	
C4225	NCB20JK-475X	C CAPACITOR	4.7uF 6.3V K	
C4902	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C4903	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4905	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C4907	NCBA1HK-152W	C CAPACITOR	1500pF 50V K	
C4908	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C4909	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4910	NCB31CK-105X	C CAPACITOR	1uF 16V K	
C4913	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4914	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4915	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4916	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4951	NCJ20JK-106X-D	C CAPACITOR		
C4954	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C4955	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C4981	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C4983	NCB31EK-153X	C CAPACITOR	0.015uF 25V K	
C4984	NCB31EK-153X	C CAPACITOR	0.015uF 25V K	
C4986	NCJ20JK-106X-D	C CAPACITOR		
C6005	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6006	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C6007	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C6008	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6009	NCB31AK-224X	C CAPACITOR	0.22uF 10V K	
C6010	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C6011	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6101	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6102	NCJ20JK-106X-D	C CAPACITOR		
C6103	NCBA1HK-221W	C CAPACITOR	220pF 50V K	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D370UC	A	GR-D375UC	D	GR-D390US	G
GR-D370US	B	GR-D375US	E	GR-D395US	H
GR-D371US	C	GR-D390UC	F	GR-D396US	J

△ Symbol No.	Part No.	Part Name	Description	Local
C6104	NCBA1HK-681W	C CAPACITOR	680pF 50V K	
C6105	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C6106	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C6107	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C6202	NCJ20JK-106X-D	C CAPACITOR		
C6203	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C6204	NCBA1HK-221W	C CAPACITOR	220pF 50V K	
C6301	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6302	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6303	NCBA1AK-683W	C CAPACITOR	0.068uF 10V K	
C6305	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C6402	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6403	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C6405	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C6501	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6502	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6503	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6505	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6506	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6509	NCBA1AK-333W	C CAPACITOR	0.033uF 10V K	
C6510	NCBA1CK-473W	C CAPACITOR	0.047uF 16V K	
C6511	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C6512	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C6701	NCB31CK-105X	C CAPACITOR	1uF 16V K	
C6702	NCB41CK-106X	C CAPACITOR	10uF 16V K	
C6704	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C6705	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C6706	NCBA1HK-221W	C CAPACITOR	220pF 50V K	
C6707	NCBA1HK-821W	C CAPACITOR	820pF 50V K	
C6802	NCJ20JK-106X-D	C CAPACITOR		
C6803	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C6804	NCBA1HK-392W	C CAPACITOR	3900pF 50V K	
C7701	NBP41EM-475X-B	TA E CAPACITOR	4.7uF 25V M	
C7702	NCB31EK-104X	C CAPACITOR	0.1uF 25V K	
C7703	NCB31CK-105X	C CAPACITOR	1uF 16V K	
C7802	NCBA1EK-682W	C CAPACITOR	6800pF 25V K	
C7803	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C7804	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C7805	NCB21CK-474X	C CAPACITOR	0.47uF 16V K	
C7806	NCB21CK-474X	C CAPACITOR	0.47uF 16V K	
C7807	NCB21CK-474X	C CAPACITOR	0.47uF 16V K	
C7808	NCB21CK-474X	C CAPACITOR	0.47uF 16V K	
C7809	NCB11CK-475X	C CAPACITOR	4.7uF 16V K	
C7811	NCB20JK-106X	C CAPACITOR	10uF 6.3V K	
C7812	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C7813	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C7814	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7815	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7816	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7817	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C7825	NDCA1HJ-470W	C CAPACITOR	47pF 50V J	
C7826	NDCA1HJ-470W	C CAPACITOR	47pF 50V J	
C8001	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C8002	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C8003	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8004	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8005	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8006	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8007	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8008	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8009	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8010	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8011	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C8012	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8013	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8018	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8021	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C8022	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C8023	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8024	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8025	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C8026	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8027	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C8028	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C8029	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C8030	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C8032	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C8034	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	

△ Symbol No.	Part No.	Part Name	Description	Local
C8035	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C8036	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
R102	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R103	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R104	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R105	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R106	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1001	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R1002	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R1003	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1004	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1006	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1007	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1008	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R1010	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1012	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R1013	NRSA6AJ-623W	MG RESISTOR	62kΩ 1/16W J	
R1014	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1015	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1016	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1017	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R1019	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1020	NRSA6AJ-753W	MG RESISTOR	75kΩ 1/16W J	
R1021	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R1022	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1023	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1024	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1026	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1027	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1028	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1029	NRSA6AJ-152W	MG RESISTOR	1.5kΩ 1/16W J	
R1030	NRSA6AJ-273W	MG RESISTOR	27kΩ 1/16W J	
R1031	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1032	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1033	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1034	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1036	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1037	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1038	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1039	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1041	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J	
R1042	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	A,B
R1044	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	A,B
R1045	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1046	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
R1047	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1048	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1049	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1050	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1051	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R1052	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1053	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R1054	NRSA6AJ-272W	MG RESISTOR	2.7kΩ 1/16W J	
R1055	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J	
R1056	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1057	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
R1059	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J	
R1060	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1061	NRSA6AJ-393W	MG RESISTOR	39kΩ 1/16W J	
R1062	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1063	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R1066	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1068	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1069	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1070	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1071	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1072	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1073	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1074	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1075	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1076	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1082	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1083	NRSA6AJ-102W	MG RESISTOR	10kΩ 1/16W J	
R1084	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1085	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1086	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1091	NRSA6AJ-182W	MG RESISTOR	1.8kΩ 1/16W J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D370UC	A	GR-D375UC	D	GR-D390US	G
GR-D370US	B	GR-D375US	E	GR-D395US	H
GR-D371US	C	GR-D390UC	F	GR-D396US	J

△ Symbol No.	Part No.	Part Name	Description	Local
R1092	NRSA6AJ-391W	MG RESISTOR	390Ω 1/16W J	
R1093	NRSA6AJ-152W	MG RESISTOR	1.5kΩ 1/16W J	
R1094	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R1103	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1104	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1105	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1110	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1112	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1116	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1118	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1119	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1120	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1122	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1146	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1601	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J	
R1602	NRSA6AJ-124W	MG RESISTOR	120kΩ 1/16W J	
R1603	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R1604	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1610	NRSA6AJ-271W	MG RESISTOR	270Ω 1/16W J	
R1611	NRSA6AJ-271W	MG RESISTOR	270Ω 1/16W J	
R1612	NRSA6AJ-683W	MG RESISTOR	68kΩ 1/16W J	
R1613	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1614	NRZ0072-R330X	MG RESISTOR	0.33Ω 1/4W F	
R1616	NRVA6AD-392W	CMF RESISTOR	3.9kΩ 1/16W D	
R1617	NRZ0072-R330X	MG RESISTOR	0.33Ω 1/4W F	
R1620	NRSA6AJ-683W	MG RESISTOR	68kΩ 1/16W J	
R1621	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1622	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1624	NRVA6AD-183W	CMF RESISTOR	18kΩ 1/16W D	
R1625	NRVA6AD-681W	CMF RESISTOR	680Ω 1/16W D	
R1629	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J	
R1635	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1636	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J	
R1637	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R1701	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R1702	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R1703	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R1704	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R1705	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R1706	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R1707	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1708	NRSA6AJ-124W	MG RESISTOR	120kΩ 1/16W J	
R1709	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1710	NRSA6AJ-124W	MG RESISTOR	120kΩ 1/16W J	
R1711	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1712	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R2201	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2202	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J	
R2203	NRSA6AJ-393W	MG RESISTOR	39kΩ 1/16W J	
R2204	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R2206	NRSA6AJ-563W	MG RESISTOR	56kΩ 1/16W J	
R2207	NRSA6AJ-563W	MG RESISTOR	56kΩ 1/16W J	
R2208	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R2209	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R2210	NRSA6AJ-821W	MG RESISTOR	820Ω 1/16W J	
R2211	NRSA6AJ-821W	MG RESISTOR	820Ω 1/16W J	
R2212	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω 1/16W J	
R2213	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω 1/16W J	
R2217	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R2402	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2403	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J	
R2407	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R2601	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R2602	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R2607	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R2608	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R2609	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R2610	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R3001	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R3002	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R3004	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R3005	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3006	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R3008	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R3011	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R3012	NRSA6AJ-821W	MG RESISTOR	820Ω 1/16W J	
R3013	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R3014	NRSA6AJ-821W	MG RESISTOR	820Ω 1/16W J	

△ Symbol No.	Part No.	Part Name	Description	Local
R3021	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
R3022	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
R3025	NRSA6AJ-121W	MG RESISTOR	120Ω 1/16W J	
R3026	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R3029	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R3030	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3032	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J	
R3033	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J	
R3034	NRSA6AD-560W	MG RESISTOR	56Ω 1/16W D	
R3035	NRSA6AD-560W	MG RESISTOR	56Ω 1/16W D	
R3036	NRSA6AD-560W	MG RESISTOR	56Ω 1/16W D	
R3037	NRSA6AD-560W	MG RESISTOR	56Ω 1/16W D	
R3038	NRSA6AD-512W	MG RESISTOR	5.1kΩ 1/16W D	
R3040	NRSA6AJ-242W	MG RESISTOR	2.4kΩ 1/16W J	
R3051	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J	
R3056	NRSA6AJ-683W	MG RESISTOR	68kΩ 1/16W J	
R3057	NRSA6AJ-683W	MG RESISTOR	68kΩ 1/16W J	
R3060	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R3061	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3062	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3063	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3066	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3069	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R3070	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R3075	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3081	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R3082	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R3083	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R3084	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R3090	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3093	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
R3094	NRSA6AJ-563W	MG RESISTOR	56kΩ 1/16W J	
R3095	NRSA6AJ-563W	MG RESISTOR	56kΩ 1/16W J	
R3096	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3097	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3098	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3099	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3100	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R3101	NRVA6AD-393W	CMF RESISTOR	39kΩ 1/16W D	
R3102	NRVA6AD-103W	CMF RESISTOR	10kΩ 1/16W D	
R3103	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R3104	NRVA6AD-183W	CMF RESISTOR	18kΩ 1/16W D	
R3105	NRVA6AD-103W	CMF RESISTOR	10kΩ 1/16W D	
R3106	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R3201	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J	
R3202	NRSA6AD-273W	MG RESISTOR	27kΩ 1/16W D	
R3203	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R3204	NRSA6AD-821W	MG RESISTOR	820Ω 1/16W D	
R3208	NRSA6AD-821W	MG RESISTOR	820Ω 1/16W D	
R3501	NRSA6AJ-471W	MG RESISTOR	470Ω 1/16W J	
R3502	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R3503	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R3504	NRSA6AD-241W	MG RESISTOR	240Ω 1/16W D	
R3505	NRSA6AD-241W	MG RESISTOR	240Ω 1/16W D	
R3506	NRSA6AD-241W	MG RESISTOR	240Ω 1/16W D	
R3507	NRSA6AD-241W	MG RESISTOR	240Ω 1/16W D	
R3508	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R3516	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3517	NRSA6AJ-563W	MG RESISTOR	56kΩ 1/16W J	
R3518	NRSA6AJ-622W	MG RESISTOR	6.2kΩ 1/16W J	
R3519	NRSA6AJ-303W	MG RESISTOR	30kΩ 1/16W J	
R3520	NRSA6AJ-272W	MG RESISTOR	2.7kΩ 1/16W J	
R3701	NRSA6AD-151W	MG RESISTOR	150Ω 1/16W D	
R3708	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D	
R3720	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3722	NRSA6AD-151W	MG RESISTOR	150Ω 1/16W D	
R3725	NRSA6AD-151W	MG RESISTOR	150Ω 1/16W D	
R3728	NRSA6AD-151W	MG RESISTOR	150Ω 1/16W D	
R4201	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R4203	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4204	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R4205	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R4206	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R4207	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R4208	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4209	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R4216	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J	
R4217	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D370UC	A	GR-D375UC	D	GR-D390US	G
GR-D370US	B	GR-D375US	E	GR-D395US	H
GR-D371US	C	GR-D390UC	F	GR-D396US	J

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
R4218	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R6513	NRSA6AJ-272W	MG RESISTOR	2.7kΩ 1/16W J	
R4219	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R6514	NRSA6AJ-682W	MG RESISTOR	6.8kΩ 1/16W J	
R4220	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J		R6515	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4221	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R6519	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R4901	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R6702	NRV142F-R20X	CMF RESISTOR	0.2Ω 1/4W F	
R4902	NRSA6AJ-124W	MG RESISTOR	120kΩ 1/16W J		R6704	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R4903	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R6705	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R4904	NRSA6AJ-331W	MG RESISTOR	330Ω 1/16W J		R6708	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
R4905	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J		R6709	NRSA6AJ-114W	MG RESISTOR	110kΩ 1/16W J	
R4906	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R6710	NRSA6AJ-124W	MG RESISTOR	120kΩ 1/16W J	
R4907	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R6712	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J	
R4908	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R6713	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R4909	NRVA63D-104X	CMF RESISTOR	100kΩ 1/16W D		R6714	NRSA6AJ-471W	MG RESISTOR	470Ω 1/16W J	
R4910	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J		R6715	NRSA6AD-472W	MG RESISTOR	4.7kΩ 1/16W D	
R4911	NRSA6AJ-243W	MG RESISTOR	24kΩ 1/16W J		R6716	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
R4914	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R6717	NRSA6AD-183W	MG RESISTOR	18kΩ 1/16W D	
R4915	NRSA6AJ-683W	MG RESISTOR	68kΩ 1/16W J		R6721	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4917	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R6802	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R4918	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R6803	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4919	NRSA6AJ-393W	MG RESISTOR	39kΩ 1/16W J		R7701	NRSA6AD-393W	MG RESISTOR	39kΩ 1/16W D	
R4921	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J		R7702	NRSA6AD-682W	MG RESISTOR	6.8kΩ 1/16W D	
R4922	NRSA6AJ-274W	MG RESISTOR	270kΩ 1/16W J		R7703	NRSA6AD-123W	MG RESISTOR	12kΩ 1/16W D	
R4923	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J		R7704	NRSA6AD-123W	MG RESISTOR	12kΩ 1/16W D	
R4924	NRSA6AJ-273W	MG RESISTOR	27kΩ 1/16W J		R7705	NRSA6AD-123W	MG RESISTOR	12kΩ 1/16W D	
R4930	NRSA6AJ-182W	MG RESISTOR	1.8kΩ 1/16W J		R7706	NRSA6AD-222W	MG RESISTOR	2.2kΩ 1/16W D	
R4931	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R7707	NRSA6AD-222W	MG RESISTOR	2.2kΩ 1/16W D	
R4932	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R7708	NRSA6AD-222W	MG RESISTOR	2.2kΩ 1/16W D	
R4933	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R7712	NRSA6AJ-682W	MG RESISTOR	6.8kΩ 1/16W J	
R4934	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J		R7713	NRSA6AJ-682W	MG RESISTOR	6.8kΩ 1/16W J	
R4935	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J		R7714	NRSA6AJ-682W	MG RESISTOR	6.8kΩ 1/16W J	
R4936	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J		R7721	NRSA02J-0R0X	MG RESISTOR	0Ω 1/10W J	
R4937	NRSA6AJ-122W	MG RESISTOR	1.2kΩ 1/16W J		R7802	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R4938	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R7803	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4940	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R7804	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4941	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R7805	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4942	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R7806	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4943	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J		R7807	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4944	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R7808	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4945	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J		R7809	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J	
R4951	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R7810	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J	
R4952	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R7811	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4953	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R7812	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4954	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R8002	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R4955	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J		R8008	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J	
R4956	NRSA6AJ-4R7W	MG RESISTOR	4.7Ω 1/16W J		R8009	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R4957	NRSA6AJ-4R7W	MG RESISTOR	4.7Ω 1/16W J		R8011	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4959	NRSA6AJ-4R7W	MG RESISTOR	4.7Ω 1/16W J		R8012	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4960	NRSA6AJ-4R7W	MG RESISTOR	4.7Ω 1/16W J		R8015	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R4961	NRSA6AJ-271W	MG RESISTOR	270Ω 1/16W J		R8016	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R4970	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J		R8017	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R4981	NRSA6AJ-182W	MG RESISTOR	1.8kΩ 1/16W J		R8019	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4982	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R8021	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4983	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R8022	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4984	NRSA6AJ-684W	MG RESISTOR	680kΩ 1/16W J		R8023	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R4985	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R8025	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R4986	NRSA6AJ-824W	MG RESISTOR	820kΩ 1/16W J		R8031	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R4987	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J		R8032	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4988	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R8041	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R4989	NRSA6AJ-683W	MG RESISTOR	68kΩ 1/16W J		R8042	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R4990	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J		R8046	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J	
R6001	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R8050	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R6005	NRVA6AD-303W	CMF RESISTOR	30kΩ 1/16W D		R8051	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R6008	NRVA6AD-823W	CMF RESISTOR	82kΩ 1/16W D		R8054	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R6009	NRVA6AD-333W	CMF RESISTOR	33kΩ 1/16W D		R8056	NRSA6AJ-152W	MG RESISTOR	1.5kΩ 1/16W J	
△ R6010	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R8058	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6103	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J		R8059	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R6105	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J		RA1001	NRZ0034-473W	NET RESISTOR	47kΩ 1/32W J	
R6106	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		RA1002	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
R6107	NRSA6AD-243W	MG RESISTOR	24kΩ 1/16W D		RA1003	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
R6108	NRSA6AD-363W	MG RESISTOR	36kΩ 1/16W D		RA1004	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
R6110	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		RA1005	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
R6204	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J		RA1006	NRZ0034-102W	NET RESISTOR	1kΩ 1/32W J	
R6303	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		RA1007	NRZ0034-102W	NET RESISTOR	1kΩ 1/32W J	
R6304	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J		RA4201	NRZ0034-101W	NET RESISTOR	100Ω 1/32W J	
R6305	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		RA4202	NRZ0034-101W	NET RESISTOR	100Ω 1/32W J	
R6403	NRSA6AJ-273W	MG RESISTOR	27kΩ 1/16W J		RA8001	NRZ0034-101W	NET RESISTOR	100Ω 1/32W J	
R6404	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J		RA8002	NRZ0034-101W	NET RESISTOR	100Ω 1/32W J	
R6512	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J		RA8003	NRZ0034-101W	NET RESISTOR	100Ω 1/32W J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D370UC	A	GR-D375UC	D	GR-D390US	G
GR-D370US	B	GR-D375US	E	GR-D395US	H
GR-D371US	C	GR-D390UC	F	GR-D396US	J

△ Symbol No.	Part No.	Part Name	Description	Local
RA8004	NRZ0034-101W	NET RESISTOR	100Ω 1/32W J	
RA8005	NRZ0034-103W	NET RESISTOR	10kΩ 1/32W J	
L1001	NQLC32M-100X	COIL	10uH M	
L1601	NQLC32M-100X	COIL	10uH M	
L1602	NQLC32M-100X	COIL	10uH M	
L2401	NQLC32M-100X	COIL	10uH M	
L2402	NQLC32M-100X	COIL	10uH M	
L2403	NQLC32M-100X	COIL	10uH M	
L2601	NQR0602-001X	FERRITE BEADS		
L2602	NQR0602-001X	FERRITE BEADS		
L2603	NQR0602-001X	FERRITE BEADS		
L3001	NQR0602-001X	FERRITE BEADS		
L3003	NQR0602-001X	FERRITE BEADS		
L3004	NQR0602-001X	FERRITE BEADS		
L3005	NQR0602-001X	FERRITE BEADS		
L3007	NQR0602-001X	FERRITE BEADS		
L3009	NQR0602-001X	FERRITE BEADS		
L3010	NQL085J-100X	COIL	10uH J	
L3012	NQL085J-2R7X	COIL	2.7uH J	
L3013	NQL38DK-100X	P COIL	10uH K	
L3201	NQR0602-001X	FERRITE BEADS		
L3202	NQR0602-001X	FERRITE BEADS		
L3203	NQR0602-001X	FERRITE BEADS		
L3204	NQL38DK-100X	P COIL	10uH K	
L3501	NQR0602-001X	FERRITE BEADS		
L3502	NQLC32M-100X	COIL	10uH M	
L3503	NQR0602-001X	FERRITE BEADS		
L4201	NQL38DK-100X	P COIL	10uH K	
L4202	NQL315K-220X	COIL	22uH K	
L4203	NQL315K-220X	COIL	22uH K	
L4204	NQL315K-220X	COIL	22uH K	
L4205	NQR0129-001X	FERRITE BEADS		
L4901	NQR0602-001X	FERRITE BEADS		
L4954	NQL38DK-100X	P COIL	10uH K	
L4955	NQL38DK-100X	P COIL	10uH K	
L6101	NQL87EN-390X	COIL	39uH N	
L6201	NQL87EN-390X	COIL	39uH N	
L6301	NQL62EM-470X	COIL	47uH M	
L6401	NQL62EM-470X	COIL	47uH M	
△ L6501	NQL52EM-221X	COIL	220uH M	
L6502	NQL38DK-100X	P COIL	10uH K	
L6701	NQL52EM-390X	COIL	39uH M	
L6802	NQL365K-470X	COIL	47uH K	
L7801	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
L7802	NQR0602-001X	FERRITE BEADS		
L7803	NQL382M-101X	COIL	100uH M	
L8001	NQR0129-002X	FERRITE BEADS		
L8002	NQR0129-002X	FERRITE BEADS		
L8003	NQR0129-002X	FERRITE BEADS		
L8005	NQR0129-002X	FERRITE BEADS		
L8006	NQR0006-001X	FERRITE BEADS		
L8007	NQR0129-002X	FERRITE BEADS		
L8008	NQL402M-100X	COIL	10uH M	
L8010	NQR0536-001X	CHOKE COIL		
CN101	QGF0508F3-40X	CONNECTOR	REAR FFC/FPC (1-40)	
CN102	QGB0519J1-20X	CONNECTOR	JIG CN B-B (1-20)	
CN103	QGF0549C2-30W	CONNECTOR	OPE FFC/FPC (1-30)	
CN1601	QGF0543F3-08X	CONNECTOR	LMENC FFC/FPC (1-8)	
CN1602	QGF0543F3-11X	CONNECTOR	DRUM FFC/FPC (1-11)	
CN1603	QGF0543F3-18X	CONNECTOR	CAPSTAN FFC/FPC (1-18)	
CN1604	QGF0543F3-16X	CONNECTOR	SENSOR FFC/FPC (1-16)	
CN2601	QGA1001F1-04X	CONNECTOR	MIC W-B (1-4)	
CN3501	QGF0543F3-08X	CONNECTOR	HEAD FFC/FPC (1-8)	
CN4201	QGF0549C2-20W	CONNECTOR	CCD FFC/FPC (1-20)	
CN4901	QGF0549C2-26W	CONNECTOR	OP FFC/FPC (1-26)	
CN7801	QGF0549C2-24W	CONNECTOR	VF FFC/FPC (1-24)	
△ F1601	NMFZ007-R20X-K	FUSE		
△ F1602	NMFZ007-R50X-K	FUSE		
△ F4951	NMFZ007-R25X-K	FUSE		
△ F6001	NMFZ007-2R5X-K	FUSE		
J101	QNA0040-001	DC JACK	DCJACK	
J102	QNZ0822-001	D CONNECTOR	DVJACK	
J103	QNZ0617-001	USB CONNECTOR	USB	
X1001	NAX0645-001X	CRYSTAL		
X1002	NAX0564-001X	CRYSTAL		
X4201	NAX0804-001X	CRYSTAL		

△ Symbol No.	Part No.	Part Name	Description	Local
X8001	NAX0398-001X	C OSCILLATOR		
HD1	LY35153-001D	HOLDER (LED)	LED HOLDER	
OT1	LY30035-013A	SPACER(A)	FOR LED	

CCD BOARD ASSEMBLY <02>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	LYA20025-02B	CCD BOARD ASSY		
Q5001	2SC3931/CD/-X	TRANSISTOR		
Q5001	or 2SC4265JC07-X	TRANSISTOR		
Q5002	2SC4081/QR/-X	TRANSISTOR	S5 ONLY	
C5001	NCB11CK-475X	C CAPACITOR	4.7uF 16V K	
C5002	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5004	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5005	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5006	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5007	NCB31EK-222X	C CAPACITOR	2200pF 25V K	
R5001	NRSA63J-472X	MG RESISTOR	4.7kΩ 1/16W J	
R5002	NRSA63J-472X	MG RESISTOR	4.7kΩ 1/16W J	
L5001	NQL315K-100X	COIL	10uH K	
L5002	NQL315K-100X	COIL	10uH K	

REAR BOARD ASSEMBLY <03>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	LYA20024-03C	REAR BOARD ASSY		
D501	EMZ6.8N-X	Z DIODE	EMZ6.8N-X	
D504	EMZ6.8N-X	Z DIODE	EMZ6.8N-X	
C503	NCB31CK-103X	C CAPACITOR	0.01uF 16V K	
C504	NCB31CK-103X	C CAPACITOR	0.01uF 16V K	
C505	NCB31CK-103X	C CAPACITOR	0.01uF 16V K	
C506	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C508	NCB31CK-105X	C CAPACITOR	1uF 16V K	
R501	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J	
R502	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J	
R503	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R504	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R505	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R506	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R507	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R508	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R509	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R510	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R511	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R512	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R513	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R514	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
L501	NQR0251-004X	FERRITE BEADS		
L502	NQR0251-004X	FERRITE BEADS		
L503	NQR0006-001X	FERRITE BEADS		
L504	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
△ BT501	QAB0025-001	LITHIUM BATTERY		
BT502	LY35060-001B	BATT.TERM.UNIT		
CN501	QGF0508F3-40X	CONNECTOR	TO MAINSS FFC/FPC (1-40)	
CN502	QGF0534F3-07X	CONNECTOR	TO POWER FFC/FPC (1-7)	
CN503	NNZ0151-001X	SD CARD CONNE	NNZ151(SD)	
J501	QNS0264-001	3.5 JACK	AVJACK	
S501	NSW0162-001X	DETECT SWITCH	EJECT	
OT1	LY30034-038A	SPACER(A)	SD CN	
WR1	QUQK05-40X4BA-E	FFC WIRE	REAR FFC 40pin 4.5cm	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D370UC	A	GR-D375UC	D	GR-D390US	G
GR-D370US	B	GR-D375US	E	GR-D395US	H
GR-D371US	C	GR-D390UC	F	GR-D396US	J

OPE BOARD ASSEMBLY <04>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	LYA20026-02C	OPE BOARD ASSY		
R401	NRSA63J-332X	MG RESISTOR	3.3kΩ 1/16W J	
R402	NRSA63J-682X	MG RESISTOR	6.8kΩ 1/16W J	
R403	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R404	NRSA63J-332X	MG RESISTOR	3.3kΩ 1/16W J	
R405	NRSA63J-682X	MG RESISTOR	6.8kΩ 1/16W J	
R406	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
CN401	QGF0543F3-30X	CONNECTOR	TO MAIN FFC/FPC (1-30)	
CN402	QGF0528F4-18X	CONNECTOR	TO MONITOR FFC/FPC (1-18)	
CN403	QGF0534F3-08X	CONNECTOR	TO ZOOM FFC/FPC (1-8)	
CN404	QGA1001F1-02X	CONNECTOR	TO SPK W-B (1-2)	
S401	NSW0225-001X	DETECT SWITCH	MONI SW	
S402	NSW0198-001X	TACT SWITCH	SET_SW	
S403	NSW0099-001X	SLIDE SWITCH	NSW99X(SD)	
S404	NSW0198-001X	TACT SWITCH	MENU	
S405	NSW0198-001X	TACT SWITCH	WIDE	
S406	NSW0198-001X	TACT SWITCH	LED LIGHT	
S407	NSW0198-001X	TACT SWITCH	STOP	
S408	NSW0198-001X	TACT SWITCH	REW	
S409	NSW0198-001X	TACT SWITCH	FF	
S410	NSW0198-001X	TACT SWITCH	PLAY	
OT1	LY30035-008A	SPACER(A)		
OT2	LY41818-001A	SPACER	(x2)	
WR1	QUQK05-3005AA-E	FFC WIRE	OPE FFC 30pin 5cm	

MONITOR BOARD ASSEMBLY <05>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	LYA20023-01A	MONITOR BOARD ASSY		
IC7601	DN8797MS-X	IC		
Q7601	PUMX1-W	PAIR TRANSISTOR		
Q7601	or BC847S-X	PAIR TRANSISTOR		
Q7601	or KTC801U/G/-X	PAIR TRANSISTOR		
Q7601	or RT3CLLM/EF/-X	PAIR TRANSISTOR		
Q7601	or UMX1N-W	PAIR TRANSISTOR		
Q7602	PUMX1-W	PAIR TRANSISTOR		
Q7602	or BC847S-X	PAIR TRANSISTOR		
Q7602	or KTC801U/G/-X	PAIR TRANSISTOR		
Q7602	or RT3CLLM/EF/-X	PAIR TRANSISTOR		
Q7602	or UMX1N-W	PAIR TRANSISTOR		
D7601	RB521S-30-X	SB DIODE		
D7601	or KDR720E-X	SB DIODE		
D7602	RB521S-30-X	SB DIODE		
D7602	or KDR720E-X	SB DIODE		
D7603	RB521S-30-X	SB DIODE		
D7603	or KDR720E-X	SB DIODE		
D7604	RB521S-30-X	SB DIODE		
D7604	or KDR720E-X	SB DIODE		
D7605	NSSW008C/T052-X	LED	LED	
D7605	or HEW1142LS/93/-X	LED	LED	
D7606	NSSW008C/T052-X	LED	LED	
D7606	or HEW1142LS/93/-X	LED	LED	
D7607	NSSW008C/T052-X	LED	LED	
D7607	or HEW1142LS/93/-X	LED	LED	
C7601	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7602	NCB31CK-224X	C CAPACITOR	0.22uF 16V K	
C7603	NCB31EK-153X	C CAPACITOR	0.015uF 25V K	
C7606	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7607	NCB11EK-105X	C CAPACITOR	1uF 25V K	
C7608	NCB11EK-105X	C CAPACITOR	1uF 25V K	
C7609	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7610	NCB11EK-105X	C CAPACITOR	1uF 25V K	
C7611	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7612	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7613	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7614	NCB21CK-105X	C CAPACITOR	1uF 16V K	

△ Symbol No.	Part No.	Part Name	Description	Local
C7615	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7622	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7623	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7624	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7625	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
R7601	NRSA63J-104X	MG RESISTOR	100kΩ 1/16W J	
R7603	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7604	NRSA63D-223X	MG RESISTOR	22kΩ 1/16W D	
R7605	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7606	NRSA63J-106X	MG RESISTOR	10MΩ 1/16W J	
R7609	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7610	NRSA63D-912X	MG RESISTOR	9.1kΩ 1/16W D	
R7611	NRSA63D-912X	MG RESISTOR	9.1kΩ 1/16W D	
R7612	NRSA63D-912X	MG RESISTOR	9.1kΩ 1/16W D	
R7613	NRSA63D-103X	MG RESISTOR	10kΩ 1/16W D	
R7614	NRSA63D-103X	MG RESISTOR	10kΩ 1/16W D	
R7615	NRSA63D-103X	MG RESISTOR	10kΩ 1/16W D	
R7616	NRSA63J-332X	MG RESISTOR	3.3kΩ 1/16W J	
R7617	NRSA63J-682X	MG RESISTOR	6.8kΩ 1/16W J	
R7618	NRSA63J-470X	MG RESISTOR	47Ω 1/16W J	
R7619	NRSA63J-470X	MG RESISTOR	47Ω 1/16W J	
R7620	NRSA63J-470X	MG RESISTOR	47Ω 1/16W J	
L7602	NRSA02J-0R0X	MG RESISTOR	0Ω 1/10W J	
L7603	NRSA02J-0R0X	MG RESISTOR	0Ω 1/10W J	
L7604	NRSA02J-0R0X	MG RESISTOR	0Ω 1/10W J	
CN7601	QGF0312F1-21W	CONNECTOR	TO OPE FFC/FPC (1-21)	
CN7602	QGF0528F4-40X	CONNECTOR	FFC/FPC (1-40)	
WR1	QAL0785-001	FPC		

VF BOARD ASSEMBLY <06>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	LYA20027-01B	VF BOARD ASSY		
Q7001	PUMX1-W	PAIR TRANSISTOR		
Q7001	or BC847S-X	PAIR TRANSISTOR		
Q7001	or KTC801U/G/-X	PAIR TRANSISTOR		
Q7001	or RT3CLLM/EF/-X	PAIR TRANSISTOR		
Q7001	or UMX1N-W	PAIR TRANSISTOR		
D7001	E1S35AW0C501-X	LED		
D7002	UDZS5.1B-X	Z DIODE		
C7001	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7002	NCB21CK-474X	C CAPACITOR	0.47uF 16V K	
R7001	NRSA63J-332X	MG RESISTOR	3.3kΩ 1/16W J	
R7002	NRSA63J-561X	MG RESISTOR	560Ω 1/16W J	
R7003	NRSA63J-470X	MG RESISTOR	47Ω 1/16W J	
CN7001	QGF0543F3-23X	CONNECTOR	TO MAIN FFC/FPC (1-23)	
CN7002	QGF0543F3-22X	CONNECTOR	TO VF LCD FFC/FPC (1-22)	
S7001	NSW0271-001X	DETECT SWITCH	VF SW	

JVC

SERVICE MANUAL

MECHANISM ASSEMBLY

DVC MECHANISM




TABLE OF CONTENTS

1	JIGS AND TOOLS	1-2
2	SPECIFIC SERVICE INSTRUCTIONS	1-3
3	PARTS LIST	3-1

SECTION 1

JIGS AND TOOLS

1.1 TOOLS REQUIRED FOR ADJUSTMENTS







1. Torque driver YTU94088	2. Bit YTU94088-003
	
3. Tweezers P-895	4. Chip IC replacement jig PTS40844-2
	
5. Guide driver YTU94148A-1	6. Cleaning cloth KSMM-01
	

Fig.1-1-1

1. Torque driver

Be sure to use to fastening the mechanism and exterior parts because those parts must strictly be controlled for tightening torque.

Torque setting value of torque driver is limited. At the values over the maximum torque setting value, fasten a screw manually not to damage the screw thread.

2. Bit

This bit is slightly longer than those set in conventional torque drivers.

3. Tweezers

To be used for removing and installing parts and wires.

4. Chip IC replacement jig

To be used for replacement of part.

5. Guide driver

To be used for the height adjustment such as the guide rollers.

6. Cleaning cloth

Recommended cleaning cloth to wipe down the video heads, mechanism (tape transport system), optical lens surface.

SECTION 2

SPECIFIC SERVICE INSTRUCTIONS

2.1 DVC MECHANISM

2.1.1 Precautions

- (1) When fastening parts, pay careful attention to the tightening torque of each screw. Unless otherwise specified, tighten a screw with the torque of 0.055 N·m (0.56 kgf·cm).
- (2) Be sure to disconnect the set from the power supply before fastening and soldering parts.
- (3) When disconnecting/connecting wires, be careful not to get them and their connectors damaged.
- (4) When replacing parts, be very careful neither to damage other parts nor to fit wrong parts by mistake.

2.1.2 Notes on procedure for disassembly/assembly

The DISASSEMBLY PROCEDURE TABLE shows the procedure to disassemble/reassemble mechanism parts.

Carefully read the following explanation before starting actual disassembling/reassembling work. The item numbers(circled numbers)in the following explanation correspond to those appearing under respective columns of the table.

Example

NO.	PART NAME	FIG.	POINT	NOTE	REMARKS
[1]	CASSETTE HOUSING ASSY	T Fig.2-4-3	3(S1),(L1a)-(L1e)	NOTE 1 a,b,c,d	ADJUSTMENT
[2]	UPPER BASE ASSY	T Fig.2-4-4	(S2),(L2a),(L2b)	NOTE 2	
[3]	DRUM ASSY	T	(S3a),2(S3b)	NOTE 3 a,b	
[4]	REEL DISK ASSY(SUP)	T Fig.2-4-5	(W4)	NOTE 4 a	
[5]	REEL DISK ASSY(TU)	T	(W5a),(W5b),(W5c)	NOTE 5 a,b	
[6]	REEL COVER ASSY	T	(W6),(S6a),2(S6b)	NOTE 6	ADJUSTMENT

↑
*1

↑
*2

↑
*3

↑
*4

↑
*5

↑
*6

↑
*7

*1 Numbers appearing in this column indicate the order to remove parts. When reassembling, follow these numbers in the reverse order. Circled numbers in this column correspond to those appearing in drawings of this section.

*2 This column shows part names corresponding to numbers in the left column.

*3 The symbol (T or B)appearing in this column shows the side which the objective part is mounted on.
T =the upper side, B =the lower side

*4 Symbols appearing in this column indicate drawing numbers.

*5 This column indicates parts and points such as screws, washers,springs,and others to be removed/fitted for disassembling/reassembling the mechanism. Besides such the parts, this column occasionally indicates working points.

P = Spring

W = Washer

S = Screw

* = Lock (L),soldering (SD),shield,connector (CN),etc.

*6 Numbers in this column represent the numbers of notes in the text.

(For parts that need phase adjustment after reassembling, refer to "MECHANISM ADJUSTMENTS".)

*7 This column indicates required after-disassembling/-reassembling work such as phase adjustment or mechanism adjustment.

Example

- Remove (W1)=Washer W1.
- Remove the solder at (SD1)=Point SD1.
- Disconnect A = Connector A.

2.1.3 DISASSEMBLY AND ASSEMBLY OF MECHANISM ASSEMBLY

2.1.3.1 General statement

The mechanism should be disassembled/assembled in the CASS IN mode (ASSEMBLY mode). (Refer to Fig. 2-1-2,2-1-5.) When the mechanism assembly is removed from the main body, it is generally set in the STOP mode.

After the mechanism assembly is removed from the main body, it is required to forcibly supply 3V DC to the LOADING MOTOR to unload, and then set the CASS IN mode.

<Mechanism assembly/Cassette housing assembly>




Fig.2-1-1

<Back side of the mechanism assembly>




Fig.2-1-2

2.1.3.2 Mechanism modes

The mechanism mode of this model is classified into five modes as shown in Fig. 2-1-9. Each mechanism mode can be distinguished from others by the relative position of "△", "○", "□" marks on the sub cam gear to the inner or outer protrusion on the main deck. Refer to Fig. 2-1-3 to 2-1-8 below.




Fig.2-1-3

<Confirmation of mode>

➡ : HOLE(Penetration)

⇨ : Half Panch




Fig.2-1-4




Fig.2-1-5




Fig.2-1-6




Fig.2-1-7




Fig.2-1-8

2.1.3.3 Mechanism timing chart





Fig.2-1-9


2.1.4 DISASSEMBLY PROCEDURE TABLE

MARK: # After assembly, perform adjustments.


NO.	PART NAME		FIG.	POINT	NOTE	REMARKS
[1]	HOUSING ASSY	T	1	2(S1),L1a,b,c,d	NOTE1a,b	ADJUSTMENT
[2]	DRUM PROTECTOR	T	2	S2,L2a,b	NOTE2	
[3]	DRUM ASSY	T		3(S3),L3a,b	NOTE3a,b	#
[4]	REEL COVER ASSY	T		2(S4),2(L4a),L4b,c	NOTE4	
[5]	IDLER ARM ASSY	T	3	-	-	
[6]	T5 ARM ASSY	T		L6a,b	NOTE6a,b	ADJUSTMENT
[7]	TENSION ARM ASSY	T		L7a,S7,L7b,2(L7c)	NOTE7a,b,c	ADJUSTMENT/#
[8]	S1 ARM ASSY	T		L8	NOTE8	ADJUSTMENT
[9]	SLIDE GUIDE PLATE	T	4	S9,L9	NOTE9a,b	ADJUSTMENT/#
[10]	GUIDE PLATE	T		S10,L10	-	ADJUSTMENT
[11]	SLIDE DECK ASSY	T		2(L11a),3(L11b),2(L11c)	NOTE11a,b	ADJUSTMENT/#
[12]	CASSETTE GUIDE	T	5-1	S12,2(L12)	-	
[13]	PINCH ROLLER ARM ASSY	T	5-2	L13	NOTE13a,b,c	
[14]	REEL DISK ASSY (SUP)	T		L14	NOTE14a,b	
[15]	REEL DISK ASSY (TU)	T		L15	NOTE15a,b,c	
[16]	BRAKE PLATE	T		-	NOTE16	ADJUSTMENT
[17]	T. C. PLATE ASSY	T	6	L17,SLIDE COLLAR1	NOTE17	
[18]	DRUM BASE	T		3(S18),L18a,2(L18b)	NOTE18	
[19]	DRIVE ARM ASSY	T		L19,SLIDE COLLAR2	NOTE19a,b	ADJUSTMENT
[20]	GUIDE RAIL ASSY	T	7	S20	NOTE20	ADJUSTMENT/#
[21]	T5 CATCHER	T		S21,L21	-	
[22]	CAPSTAN MOTOR	T		2(S22)	NOTE22	
[23]	REEL PULLEY	T		-	-	
[24]	CENTER GEAR	T	8	-	-	
[25]	MOTOR BRACKET ASSY	T		S25	NOTE25a,b,c	
[26]	BELT GUIDE	T		S26,2(L26)	-	
[27]	GEAR COVER	T		3(S27),L27a,b,c,d	NOTE27	ADJUSTMENT
[28]	PRESS ARM ASSY	T	9	L28	NOTE28	ADJUSTMENT
[29]	SUB CAM	T		-	NOTE29	PHASE ADJUSTMENT
[30]	CONNECT GEAR	T		-	NOTE30	
[31]	MAIN CAM	T	10	-	NOTE31	PHASE ADJUSTMENT
[32]	ROTARY ENCODER	T		L32	NOTE32	PHASE ADJUSTMENT
[33]	LOADING GEAR 1	T		-	-	
[34]	GUIDE ROLLER (S) ASSY	T		-	NOTE34a,b	#
[35]	COMPRESSION SPRING	T		-	NOTE35	
[36]	MAIN DECK ASSY	T		-	-	#



< TOP VIEW >



< BOTTOM VIEW >



2.1.5 DISASSEMBLY/ASSEMBLY

2.1.5.1 [1] HOUSING ASSY

NOTE1a:

When disassembling/ assembling the MECHANISM ASSY, make sure to remove the HOUSING ASSY.

When removing the HOUSING ASSY, make sure to bring the HOUSING ASSY up either by changing the mechanism mode to the EJECT mode, or by moving the EJECT LEVER to the direction as indicated by the arrow.

During the procedure, make sure to return to the CASS IN mode if the mode was changed.

NOTE1b:

Be careful not to damage the LEFT ARM2, RIGHT ARM2 during work.





Fig.1

2.1.5.2 [2] DRUM PROTECTOR

[3] DRUM ASSY

[4] REEL COVER ASSY

NOTE2:

During the procedure, be careful in handling the FPC.

NOTE3a:

When removing, carefully hold the top center of the DRUM ASSY with fingers otherwise it may possibly fall off.

NOTE3b:

Pay extra attention to the soil, dust and scratch on the surface. During the procedure, be careful not to cut/ damage the FPC.

NOTE4:

During the procedure, remove the LED from the REEL COVER ASSY first to set the FPC free, remove the two screws (7, 8), then remove the REEL COVER ASSY by sliding it to the direction as indicated by the arrow.

During the procedure, be careful in handling the FPC.





Fig.2

**2.1.5.3 [5] IDLER ARM ASSY
[6] T5 ARM ASSY
[7] TENSION ARM ASSY**

NOTE6a:


There are two types of the T5 ARM ASSY. They are different in shape. The old type is without a hook and the new type is with a hook.

When an old type is replaced by a new type, replace the PINCH ROLLER ARM ASSY at the same time as the proper combination of the parts is required.

When removing, remove the spring from the hook first if there is a hook.

NOTE6b:

When mounting, pay attention to the correct positioning.



NOTE7a:

During the procedure, be careful in handling the TENSION BAND.


NOTE7b:

When mounting, attach the TENSION BAND along the groove of the gear.

NOTE7c:

When mounting, pay attention to the correct positioning.
When mounting, attach the TENSION ARM ASSY with the plate moved to the direction as indicated by the arrow.
If the plate is moved to the other direction, the TENSION BAND may break during the operation check as there is too much tension.

After the mounting, adjust the TENSION ARM ASSY.



**2.1.5.4 [8] S1 ARM ASSY
[9] SLIDE GUIDE PLATE
[10] GUIDE PLATE**

NOTE8:

When mounting, pay attention to the correct positioning.

NOTE9a:

When mounting, pay attention to the correct positioning.

NOTE9b:

After attachment, adjust the SLIDE GUIDE PLATE.




Fig.3




Fig.4


2.1.5.5 [11] SLIDE DECK ASSY

NOTE11a:

When removing, set the FPC free first.
During the procedure, be careful not to cut the FPC.

NOTE11b:

During the procedure, be careful in handling.



2.1.5.6 [12] CASSETTE GUIDE

[13] PINCH ROLLER ASSY

[14] REEL DISK ASSY (SUP)

[15] REEL DISK ASSY (TU)

[16] BRAKE PLATE

NOTE13a:


The spring attachment differs according to the types of the T5 ARM ASSY. The spring is attached either to the hook of the SLIDE DECK ASSY or to the hook of the T5 ARM ASSY. When an old type is replaced by a new type, replace the T5 ARM ASSY at the same time as the proper combination of the parts is required. When removing, remove the spring only when the spring is attached to the SLIDE DECK ASSY. Be careful when attaching as the spring has been removed if it was attached to the T5 ARM ASSY.

NOTE13b:

During the procedure, be careful in handling.
Pay extra attention to the soil, dust and scratch on the ROLLER.

NOTE13c:

Be sure to place this part beneath the SLIDE DECK ASSY.



NOTE14a:

When removing, be careful not to damage or open too much the hook as there is only one hook in a narrow part.

NOTE14b:

Be careful not to attach the REEL DISK wrongly. The Supply side can be identified by the white color at the center.

NOTE 15a:

When removing, be careful not to damage or open too much the hook as there is only one hook in a narrow part.

NOTE 15b:

Be careful not to attach the REEL DISK wrongly. The Take-up side can be identified by the black color at the center.

NOTE 15c:

When removing the REEL DISK ASSY, be careful in handling as the BRAKE PLATE which is located under the REEL DISK ASSY becomes free.

NOTE 16:

During the procedure, be careful in handling.




Fig.5-1




Fig.5-2

2.1.5.7 [17] T. C. PLATE ASSY
[18] DRUM BASE
[19] DRIVE ARM ASSY

NOTE17:

During the procedure, be careful not to lose the SLIDE COLLAR1.

NOTE19a:

When mounting, pay attention to the correct positioning.

NOTE19b:

During the procedure, be careful not to lose the SLIDE COLLAR2.





Fig.6

2.1.5.8 [20] GUIDE RAIL ASSY
[21] T5CATCHER
[22] CAPSTAN MOTOR
[23] REEL PULLEY
[24] CENTER GEAR

NOTE20:

When mounting, pay attention to the correct positioning.

NOTE22:

When attaching the BELT, place the BELT inside the BELT GUIDE and roll up around the REEL PULLEY.





Fig.7

**2.1.5.9 [25] MOTOR BRACKET ASSY
[26] BELT GUIDE
[27] GEAR COVER
[28] PRESS ARM ASSY**

NOTE25a:

When disassembling, remove the four solder points (SD25) on the ROTARY ENCODER as the MOTOR BRACKET ASSY and the ROTARY ENCODER are soldered together to one FPC.

NOTE25b:

During the procedure, be careful in handling the FPC. Pay attention not to leave finger prints etc. on the surface of the DEW sensor.

NOTE25c:

During the procedure, be careful with the WORM WHEEL which is attached inside.

When mounting, attach the WORM WHEEL to the MOTOR BRACKET ASSY before mounting to the MECHANISM DECK ASSY.

NOTE27:

When removing, remove the three screws (22-24), turn the GEAR COVER anticlockwise by lifting up the parts with broken lines.

Remove L27b,c and slide the GEAR COVER by sliding to the direction shown with arrows.

When mounting, pay attention to the correct positioning.

NOTE28:

When mounting, pay attention to the correct positioning.





Fig.8



**2.1.5.10 [29] SUB CAM
[30] CONNECT GEAR
[31] MAIN CAM**

NOTE29:


When mounting, pay attention to the correct positioning.

NOTE30:

When mounting, make sure to confirm the correct positioning of the MAIN CAM, the SUB CAM, and the left and right GEAR before attachment. Although the positioning adjustment of the CONNECT GEAR itself is not necessary, the alignment of the left and right GEARS is very important.

NOTE31:


When mounting, pay attention to the correct positioning.



**2.1.5.11 [32] ROTARY ENCODER
[33] LOADING GEAR 1
[34] GUIDE ROLLER (S) ASSY
[35] COMPRESSION SPRING
[36] MAIN DECK ASSY**

NOTE32:

When mounting, pay attention to the correct positioning.



NOTE34a:

During the procedure, be careful in handling.
Pay extra attention to the soil, dust and scratch on the ROLLER.

NOTE34b:

Be sure to perform rough adjustment if the height of the GUIDE ROLLER (S) ASSY has been adjusted during the procedure. Otherwise the tape will be damaged when it is run.
For the rough adjustment, fully tighten up the GUIDE ROLLER (S) ASSY clockwise then rewind it 1.5 revolutions.
The guide measurement for the height is 17.1mm.

NOTE35:

During the procedure, be careful not to lose any parts.




Fig.9




Fig.10

2.1.6 Mechanism adjustment

1. SLIDE GUIDE PLATE adjustment

This adjustment is required when the SLIDE DECK ASSEMBLY is removed from the MAIN DECK ASSEMBLY.

The adjustment is also required when the SLIDE GUIDE PLATE is removed.

Refer to the Fig2-1-6-1 unless otherwise instructed.

Adjustment procedure

- (1) Set the PLAY mode while the HOUSING ASSEMBLY is removed. Refer to the Fig. 2-1-8.
- (2) Loosen the screw A.
- (3) Press both the MAIN DECK ASSEMBLY/ SLIDE DECK ASSEMBLY inward with an even power from both left and right. Fully pull up the SLIDE GUIDE PLATE to the left and tighten the screw A.

NOTE:

When pressing the SLIDE DECK ASSEMBLY, press near the screw hole for the HOUSING ASSEMBLY attachment. Avoid pressing the sensor as it is fragile.

NOTE:

The tightening torque is $0.078\text{N}\cdot\text{m}$ ($0.8\text{kgf}\cdot\text{cm}$)

- (4) Perform an operation check.

NOTE:

Repeat the operation check of unloading/ loading to confirm the smooth and steady slide movement without any jam or rattle.

2. Tension Arm Assembly adjustment

This adjustment is required when the Tension Arm Assembly is replaced.

Refer to the Fig.2-1-6-2 unless otherwise instructed.

Adjustment procedure

- (1) Set the Play mode while the Housing Assembly is removed. Refer to the Fig. 2-1-8.
- (2) Loosen the screw B.
- (3) Slide the Guide Plate up and down to set the tip of the Tension Arm Assembly to the edge of the screw groove, and tighten the screw B.
 - The tightening torque is $0.049\text{N}\cdot\text{m}$ ($0.5\text{kgf}\cdot\text{cm}$)
- (4) Perform an operation check.

NOTE:

Repeat loading and unloading, and make sure to check that the top of the TENSION ARM and the edge match properly when observed from the straight above.

NOTE:

The adjustable range is $\pm 0.25\text{mm}$ from the edge.





Fig.2-1-6-1




Fig.2-1-6-2

2.1.7 REMARKS

2.1.7.1 Cleaning

- (1) For cleaning of the upper drum (particularly video heads), use fine-woven cotton cloth with alcohol soaks through. Do not move the cloth but turn the upper drum counterclockwise.

NOTE:

Make sure not to move the cloth in the vertical direction to the video head, since it may cause damage of the video heads.

- (2) For cleaning of parts of the tape transport system except the upper drum, use fine-woven cotton cloth or cotton swab soaked alcohol.
- (3) After cleaning, confirm that the cleaned parts are completely dry before loading the deck with cassette tape.

2.1.7.2 Applying oil and grease

- (1) Periodical oiling and greasing are not required but should be done to new parts when replacing. If oil and grease on the other parts of the other party are old and dirty, wipe them clean and apply new oil or grease.
- (2) For parts and points to apply oil and grease, refer to the PARTS LIST.
Fig.2-1-7 specifies oil and grease to be used.
- (3) When oiling, clean the objective parts with alcohol first and apply one or two drop(s) of oil. Too much oiling causes rotary parts to slip because of oil leakage.

Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-JB	AA
Oil	YTU94027	BB
Grease (HANARL)	RX-410R	CC

specifies oil and grease to be used

Fig.2-1-7

2.1.8 SERVICE NOTE

Use the following chart to manage mechanism parts that are removed for disassembling the mechanism.















Fig.1	[1] HOUSING ASSY		Fig.2	[2] DRUM PROTECTOR	[3] DRUM ASSY
					
Fig.2	[4] REEL COVER ASSY		Fig.3	[5] IDLER ARM ASSY	[6] T5 ARM ASSY (OLD TYPE) (NEW TYPE)
					
Fig.4	[7] TENSION ARM ASSY		Fig.5-2	[8] S1 ARM ASSY	
					
Fig.5-1	[9] SLIDE GUIDE PLATE		Fig.5-2	[10] GUIDE PLATE	
					
Fig.5-1	[11] SLIDE DECK ASSY		Fig.5-2	[12] CASSETTE GUIDE	
					
Fig.5-2	[13] PINCH ROLLER ASSY		Fig.5-2	[14] REEL DISK ASSY (SUP : WHITE)	
					
Fig.5-2	[15] REEL DISK ASSY (TU : BLACK)		Fig.5-2	[16] BRAKE PLATE	
					

Fig.2-1-8-1
















Fig.6	[17] T.C.PLATE ASSY  SLIDE COLLAR1 	Fig.7	[20] GUIDE RAIL ASSY 	[22] CAPSTAN MOTOR 	[23] REEL PULLEY 
	[18] DRUM ASSY 		[21] T5 CATCHER 	[24] CENTER GEAR 	
	[19] DRIVE ARM ASSY  SLIDE COLLAR2 	Fig.8	[25] MOTOR BRACKET ASSY  WORM WHEEL 	[27] GEAR COVER 	[28] PRESS ARM ASSY 
Fig.9	[26] BELT GUIDE 		[29] SUB CAM 		[30] CONNECT GEAR 
	[31] MAIN CAM 	[32] ROTARY ENCODER 	[33] LOADING GEAR1 		[34] GUIDE ROLLER(S) ASSY [35] COMPRESSION SPRING 
	Fig.10	[36] MAIN DECK ASSY 			

Fig.2-1-8-2

2.1.9 SERVICE NOTE 2

Use the following chart to manage screws.

Symbol No.	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	[10]	[11]	[12]	[13]	[14]	[15]	[16]	[17]	[18]	[19]
Removing order of screw	1	2	3	4	5	6	7	8	-	10	11	12	-	-	-	-	-	13	14
Place to stick screw									*										15
Reference drawing (Fig.No.)	Fig.1																		
Screw tightening torque	a	b			a	-	a	-	a/c	a	-	b	Fig.5-2						Fig.6
																		b	-

Symbol No.	[20]	[21]	[22]	[23]	[24]	[25]	[26]	[27]	[28]	[29]	[30]	[31]	[32]	[33]	[34]	[35]	[36]
Removing order of screw	16	17	18	19	-	20	21	22	23	24	-	-	-	-	-	-	-
Place to stick screw					-						-	-	-	-	-	-	-
Reference drawing (Fig.No.)	Fig.7																
Screw tightening torque	a	b	-	-	Fig.8				Fig.9			Fig.10					
								b									-

Fig.2-1-7

NOTE:

- Pay careful attention to tightening torque for each screw.
 - Torque setting value of torque driver is limited. At the values over the maximum torque setting value, fasten a screw manually not to damage the screw thread.
 - a : 0.049N・m (0.5kgf・cm) b : 0.039N・m (0.4kgf・cm) c : 0.078N・m (0.8kgf・cm)
 - The tightening torque of the No.10 screw is 0.049N・m(0.5kgf・cm) for mounting, and 0.078N・m(0.8kgf・cm) for adjustment.
- For details, refer to the adjustment item "2.1.6.1 Adjustment of the SLIDE GUIDE PLATE"



Victor Company of Japan, Limited
AV & MULTIMEDIA COMPANY CAMCORDER CATEGORY 12, 3-chome, Moriya-cho, kanagawa-ku, Yokohama, kanagawa-prefecture, 221-8528, Japan

(No.YF081)



Printed in Japan
VPT


JVC

SCHEMATIC DIAGRAMS

DIGITAL VIDEO CAMERA

**GR-D370UC, GR-D370US,
GR-D371US, GR-D375UC,
GR-D375US, GR-D390UC,
GR-D390US, GR-D395US,
GR-D396US**

CD-ROM No.SML200602



Mini **DV** NTSC



MultiMediaCard

GR-D370UCM, GR-D370USM, GR-D371USM,
GR-D375UCM, GR-D375USM, GR-D390UCM,
GR-D390USM, GR-D395USM, GR-D396USM [M6D1S5]

For disassembling and assembling of MECHANISM ASSEMBLY, refer to the SERVICE MANUAL No.YF081(MECHANISM ASSEMBLY).
Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade).

CHARTS AND DIAGRAMS

NOTES OF SCHEMATIC DIAGRAM

Safety precautions

The Components identified by the symbol  are critical for safety. For continued safety, replace safety critical components only with manufacturer's recommended parts.

1. Units of components on the schematic diagram

Unless otherwise specified.

- 1) All resistance values are in ohm. 1/6 W, 1/8 W (refer to parts list).
Chip resistors are 1/16 W.
K: K Ω (1000 Ω), M: M Ω (1000K Ω)
- 2) All capacitance values are in μ F, (P: PF).
- 3) All inductance values are in μ H, (m: mH).
- 4) All diodes are 1SS133, MA165 or 1N4148M (refer to parts list).

Note: The Parts Number, value and rated voltage etc. in the Schematic Diagram are for references only. When replacing the parts, refer to the Parts List.

2. Indications of control voltage


AUX : Active at high.

$\overline{\text{AUX}}$ or AUX(L) : Active at low.


3. Interpreting Connector indications




Removable connector




Wire soldered directly on board



Non-removable Board connector



Board to Board




Connected pattern on board
The arrows indicate signal path

Note: For the destination of each signal and further line connections that are cut off from the diagram, refer to "BOARD INTERCONNECTIONS"

4. Voltage measurement

- 1) Regulator (DC/DC CONV) circuits
REC : Colour bar signal.
PB : Alignment tape (Colour bar).
— : Unmeasurable or unnecessary to measure.
- 2) Indication on schematic diagram
Voltage indications for REC and PB mode on the schematic diagram are as shown below.



Note: If the voltages are not indicated on the schematic diagram, refer to the voltage charts.

5. Signal path Symbols

The arrows indicate the signal path as follows.

NOTE : The arrow is DVC unique object.

-  Playback signal path
-  Playback and recording signal path
-  Recording signal path (including E-E signal path)
-  Capstan servo path
-  Drum servo path

(Example)

-  R-Y Playback R-Y signal path
-  Y Recording Y signal path

6. Indication of the parts for adjustments

The parts for the adjustments are surrounded with the circle as shown below.



7. Indication of the parts not mounted on the circuit board

"OPEN" is indicated by the parts not mounted on the circuit board.



CIRCUIT BOARD NOTES


1. Foil and Component sides

- 1) Foil side (B side) :
Parts on the foil side seen from foil face (pattern face) are indicated.
- 2) Component side (A side) :
Parts on the component side seen from component face (parts face) indicated.

Parts location are indicated by guide scale on the circuit board.


2. Parts location guides

Parts location are indicated by guide scale on the circuit board.




Note: For general information in service manual, please refer to the Service Manual of GENERAL INFORMATION Edition 4 No. 82054D (January 1994).


■ BOARD INTERCONNECTION



NOTES: The number of patch cords (*) are indicated by interconnected.




■ MAIN(MAIN IF) SCHEMATIC DIAGRAM




NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.



■ MAIN(CPU) SCHEMATIC DIAGRAM




NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.




ONS".

yf124_y10597001a_rev0.1

■ MAIN(MDA) SCHEMATIC DIAGRAM




NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.



yf124_y20400001a_rev0.1

ONS".


■ MAIN(AUDIO) SCHEMATIC DIAGRAM



NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.




■ MAIN(PARAGON) SCHEMATIC DIAGRAM




NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.

■ MAIN(VIDEO) SCHEMATIC DIAGRAM



NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.


0 1 MAIN(VIDEO)




yf124_y10598001a_rev0.1

ONS".

■ MAIN(PRE/REC) SCHEMATIC DIAGRAM




NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.




ONS".

yf124_y20399001a_rev0.1

■ MAIN(CDS/TG) SCHEMATIC DIAGRAM




NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.



yf124_y30342001a_rev0.1


ONS".

■ MAIN(OP DRV) SCHEMATIC DIAGRAM



NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.


0 1 MAIN(OP DRV)



yf124_y10601001a_rev0.1

■ MAIN(REG) SCHEMATIC DIAGRAM


0 1 MAIN(REG)






(No.YF124)2-24

■ MAIN(MONI/VF) SCHEMATIC DIAGRAM



NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.


■ MAIN(DSC) SCHEMATIC DIAGRAM



NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.




■ MAIN(JACK) SCHEMATIC DIAGRAM



NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.

■ CCD SCHEMATIC DIAGRAM




Ref	IC5001
Dest Key	
NTSC	M6D1S3=ICX440UKM-K M6D1S5=ICX610UKM-K
PAL	ICX611UKM-K


Ref	Q5002	R5002
Dest Key		
with_DSC	BA8447BW-X 2SC4081/QR/-X	4.7k
w/o_DSC	OPEN	OPEN

NOTES :1. For the destination of each signal and further line connectionsthat are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.
3. IC5001 is incorporated in the CCD base assembly .
When IC5001 needs replacement, replace the CCD base assembly in whole because it cannot be replaced alone.

REAR SCHEMATIC DIAGRAM



NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.



DIFFERENCE TABLE 1

Ref	Dest Key	NTSC	PAL
J502, C510, C513, L505, L506		NO	YES


DIFFERENCE TABLE 2

Ref	Dest Key	M6D1S3	M6D1S5
CN501		NO	YES
CN504		YES	NO
R503 R504 R505 R506 R507 R508 R509 R510		NO	YES
D504 L503 C505 C506 C507 CN503		NO	YES

ONS".


yf124_y30336001a_rev0.1

■ OPE AND ZOOM UNIT SCHEMATIC DIAGRAMS




NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
 2. The parts with marked (*) is not used.

VF SCHEMATIC DIAGRAM



NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.


MONITOR SCHEMATIC DIAGRAM



NOTES: 1. For the destination of each signal and further line connections that are cut off from this diagram, refer to "BOARD INTERCONNECTIONS".
2. The parts with marked (*) is not used.

TO LCD(MONITOR)
MODULE

CN7602
QGF0528F4-40X
BOTTOM CONTACT




yf124_y30335001a_rev0.1

ONS".

Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)


FOIL SIDE(




This is a detailed schematic of a printed wiring board (PWB) for a radio receiver. The board is populated with numerous integrated circuits (ICs), resistors (R), capacitors (C), inductors (L), and other components. Key ICs include IC1601, IC8001, IC8002, IC1006, IC2201, and IC1008. The board is labeled "MAIN PWB" and includes a part number "-001B" and a revision number "LYB10065". The layout shows a complex arrangement of components with various pin connections and labels.

Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)


COMPONENT S






Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)

COMPONENT SIDE(A)




FOIL SIDE(B)




**<04>OPE
LYB20026-001C**

FOIL SIDE(B)



COMPONENT SIDE(A)




■ MONITOR AND VF CIRCUIT BOARDS

Lead free solder used in the board (material : Sn-Ag-Cu, melting point : 219 Centigrade)

<05>MONITOR
LYB20023-001A



FOIL SIDE(B)



<06>VF
LYB20027-001B

FOIL SIDE(B)

COMPONENT SIDE(A)





VOLTAGE CHARTS

<MAIN> MODE PIN NO				REC	PLAY	<MAIN> MODE PIN NO				REC	PLAY
IC1001				-	-	42				0	0
IC1002						43				0	0
1				2.9	2.9	44				0	0
2				2.6	2.6	45				4.8	4.8
3				1.1	1.3	46				1.5	1.5
4				3.0	3.0	47				1.5	1.5
5				3.0	3.0	48				1.5	1.5
6				3.0	3.0	49				1.5	1.5
7				0	0	50				0	0
8				1.5	1.5	51				14.0	14.0
9				0	0	52				2.4	2.4
10				0	0	53				12.5	12.5
11				0	0	54				0	0
12				0	0	55				0	0
13				0	0	56				0	0
14				2.5	2.5	57				3.1	3.1
15				0	0	58				2.9	2.9
16				0	0	59				0	0
17				0	0	60				1.2	1.2
18				0	0	61				0.3	0.3
19				3.0	3.0	62				1.5	1.5
20				2.7	2.7	63				0.7	0.7
IC1004						64				0.9	0.9
1				1.4	1.4	IC1701					
2				0	0	1				-	-
3				1.2	1.2	2				1.4	1.4
4				0	0	3				1.4	1.4
5				3.0	3.0	4				0	0
IC1005						5				1.4	1.4
1				3.0	3.0	6				1.4	1.4
2				0.4	0.4	7				-	-
3				3.0	3.0	8				4.8	4.8
4				0	0	IC1702					
5				0	3.1	1				-	-
6				0	3.1	2				1.4	1.4
7				3.0	3.0	3				-	-
8				3.0	3.0	4				0	0
IC1006						5				0	-
1				0	0	6				1.4	1.4
2				3.0	3.1	7				-	0
3				3.1	3.1	8				4.8	4.8
4				0	0	IC2201					
5				3.0	3.0	1				0	1.6
6				0.5	0.5	2				0	0
7				0.3	0.3	3				0	1.5
8				3.1	3.1	4				3.1	3.1
IC1007						5				3.1	3.1
1				3.0	3.0	6				0	0
2				3.0	3.0	7				1.5	1.5
3				0	0	8				1.4	1.4
4				0	0	9				1.5	1.5
IC1008						10				1.3	0.9
1				3.0	3.0	11				1.1	1.1
2				0	0	12				2.5	2.5
3				3.0	3.0	13				1.4	1.4
IC1601						14				1.5	0
1				0	0	15				0.4	0.4
2				0.4	0.4	16				0.4	0.4
3				0.4	0.6	17				0.4	0.4
4				0	0	18				0	0.4
5				0.5	0.5	19				3.0	3.0
6				0	0	20				0	0
7				0	0	21				0	0.4
8				1.5	1.5	22				1.5	1.5
9				1.5	1.5	23				0.3	0.3
10				1.5	1.5	24				1.5	1.5
11				1.5	1.5	25				0	0
12				1.5	1.5	26				0	0
13				1.5	1.5	27				4.8	4.8
14				2.7	2.7	28				0	0
15				1.2	1.2	29				2.4	2.4
16				1.5	1.5	30				0	0
17				1.5	1.5	31				3.0	3.0
18				1.5	1.5	32				1.5	1.5
19				1.5	1.5	33				0.4	1.5
20				1.5	1.5	34				0.4	1.5
21				3.0	3.0	35				0	1.5
22				0.6	0.6	36				1.5	1.5
23				0.4	0.4	37				1.5	1.5
24				1.4	1.4	38				1.5	1.5
25				1.4	1.4	39				1.5	0
26				11.0	11.0	40				1.5	0
27				0	0	41				0	0
28				2.7	2.7	42				4.8	4.8
29				0.7	0.7	43				3.4	0
30				1.3	1.3	44				4.8	4.8
31				0.7	0.7	45				1.5	0
32				1.0	0.8	46				1.5	0
33				0	1.2	47				1.5	1.5
34				0	1.2	48				1.5	1.5
35				1.2	1.2	IC3001				-	-
36				0	0	IC3004					
37				1.1	1.1	1				0	0
38				0	0	2				0	1.3
39				1.5	1.5	3				1.9	1.9
40				0	0	4				2.9	2.9
41				0	0	5				1.4	1.4


[illegible]


POWER SYSTEM BLOCK DIAGRAM





VIDEO SYSTEM BLOCK DIAGRAM







Victor Company of Japan, Limited
Camcorder Category 12, 3-chome, Moriya-cho, kanagawa-ku, Yokohama, kanagawa-prefecture, 221-8528, Japan

(No.YF124)



Printed in Japan
VPT